

User's Manual



RCP 2000
Remote Control Panel

Precautions

Safety Instructions • English



This symbol is intended to alert the user of important operating and maintenance (servicing) instructions in the literature provided with the equipment.



This symbol is intended to alert the user of the presence of uninsulated dangerous voltage within the product's enclosure that may present a risk of electric shock.

Caution

Read Instructions • Read and understand all safety and operating instructions before using the equipment.

Retain Instructions • The safety instructions should be kept for future reference.

Follow Warnings • Follow all warnings and instructions marked on the equipment or in the user information.

Avoid Attachments • Do not use tools or attachments that are not recommended by the equipment manufacturer because they may be hazardous.

Consignes de Sécurité • Français



Ce symbole sert à avertir l'utilisateur que la documentation fournie avec le matériel contient des instructions importantes concernant l'exploitation et la maintenance (réparation).



Ce symbole sert à avertir l'utilisateur de la présence dans le boîtier de l'appareil de tensions dangereuses non isolées posant des risques d'électrocution.

Attention

Lire les instructions • Prendre connaissance de toutes les consignes de sécurité et d'exploitation avant d'utiliser le matériel.

Conservier les instructions • Ranger les consignes de sécurité afin de pouvoir les consulter à l'avenir.

Respecter les avertissements • Observer tous les avertissements et consignes marqués sur le matériel ou présentés dans la documentation utilisateur.

Eviter les pièces de fixation • Ne pas utiliser de pièces de fixation ni d'outils non recommandés par le fabricant du matériel car cela risquerait de poser certains dangers.

Sicherheitsanleitungen • Deutsch



Dieses Symbol soll dem Benutzer in der im Lieferumfang enthaltenen Dokumentation besonders wichtige Hinweise zur Bedienung und Wartung (Instandhaltung) geben.



Dieses Symbol soll den Benutzer darauf aufmerksam machen, daß im Inneren des Gehäuses dieses Produktes gefährliche Spannungen, die nicht isoliert sind und die einen elektrischen Schock verursachen können, herrschen.

Achtung

Lesen der Anleitungen • Bevor Sie das Gerät zum ersten Mal verwenden, sollten Sie alle Sicherheits- und Bedienungsanleitungen genau durchlesen und verstehen.

Aufbewahren der Anleitungen • Die Hinweise zur elektrischen Sicherheit des Produktes sollten Sie aufbewahren, damit Sie im Bedarfsfall darauf zurückgreifen können.

Befolgen der Warnhinweise • Befolgen Sie alle Warnhinweise und Anleitungen auf dem Gerät oder in der Benutzerdokumentation.

Keine Zusatzgeräte • Verwenden Sie keine Werkzeuge oder Zusatzgeräte, die nicht ausdrücklich vom Hersteller empfohlen wurden, da diese eine Gefahrenquelle darstellen können.

Instrucciones de seguridad • Español



Este símbolo se utiliza para advertir al usuario sobre instrucciones importantes de operación y mantenimiento (o cambio de partes) que se desean destacar en el contenido de la documentación suministrada con los equipos.



Este símbolo se utiliza para advertir al usuario sobre la presencia de elementos con voltaje peligroso sin protección aislante, que puedan encontrarse dentro de la caja o alojamiento del producto, y que puedan representar riesgo de electrocución.

Precaución

Leer las instrucciones • Leer y analizar todas las instrucciones de operación y seguridad, antes de usar el equipo.

Conservar las instrucciones • Conservar las instrucciones de seguridad para futura consulta.

Obedecer las advertencias • Todas las advertencias e instrucciones marcadas en el equipo o en la documentación del usuario, deben ser obedecidas.

Evitar el uso de accesorios • No usar herramientas o accesorios que no sean específicamente recomendados por el fabricante, ya que podrían implicar riesgos.

Warning

Power sources • This equipment should be operated only from the power source indicated on the product. This equipment is intended to be used with a main power system with a grounded (neutral) conductor. The third (grounding) pin is a safety feature, do not attempt to bypass or disable it.

Power disconnection • To remove power from the equipment safely, remove all power cords from the rear of the equipment, or the desktop power module (if detachable), or from the power source receptacle (wall plug).

Power cord protection • Power cords should be routed so that they are not likely to be stepped on or pinched by items placed upon or against them.

Servicing • Refer all servicing to qualified service personnel. There are no user-serviceable parts inside. To prevent the risk of shock, do not attempt to service this equipment yourself because opening or removing covers may expose you to dangerous voltage or other hazards.

Slots and openings • If the equipment has slots or holes in the enclosure, these are provided to prevent overheating of sensitive components inside. These openings must never be blocked by other objects.

Lithium battery • There is a danger of explosion if battery is incorrectly replaced. Replace it only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions.

Avertissement

Alimentations • Ne faire fonctionner ce matériel qu'avec la source d'alimentation indiquée sur l'appareil. Ce matériel doit être utilisé avec une alimentation principale comportant un fil de terre (neutre). Le troisième contact (de mise à la terre) constitue un dispositif de sécurité: n'essayez pas de le contourner ni de la désactiver.

Déconnexion de l'alimentation • Pour mettre le matériel hors tension sans danger, déconnectez tous les cordons d'alimentation de l'arrière de l'appareil ou du module d'alimentation de bureau (s'il est amovible) ou encore de la prise secteur.

Protection du cordon d'alimentation • Acheminer les cordons d'alimentation de manière à ce que personne ne risque de marcher dessus et à ce qu'ils ne soient pas écrasés ou pincés par des objets.

Réparation-maintenance • Faire exécuter toutes les interventions de réparation-maintenance par un technicien qualifié. Aucun des éléments internes ne peut être réparé par l'utilisateur. Afin d'éviter tout danger d'électrocution, l'utilisateur ne doit pas essayer de procéder lui-même à ces opérations car l'ouverture ou le retrait des couvercles risquent de l'exposer à de hautes tensions et autres dangers.

Fentes et orifices • Si le boîtier de l'appareil comporte des fentes ou des orifices, ceux-ci servent à empêcher les composants internes sensibles de surchauffer. Ces ouvertures ne doivent jamais être bloquées par des objets.

Lithium Batterie • Il a danger d'explosion s'il y a remplacement incorrect de la batterie. Remplacer uniquement avec une batterie du même type ou d'un type équivalent recommandé par le constructeur. Mettre au reut les batteries usagées conformément aux instructions du fabricant.

Vorsicht

Stromquellen • Dieses Gerät sollte nur über die auf dem Produkt angegebene Stromquelle betrieben werden. Dieses Gerät wurde für eine Verwendung mit einer Hauptstromleitung mit einem geerdeten (neutralen) Leiter konzipiert. Der dritte Kontakt ist für einen Erdschluss, und stellt eine Sicherheitsfunktion dar. Diese sollte nicht umgangen oder außer Betrieb gesetzt werden.

Stromunterbrechung • Um das Gerät auf sichere Weise vom Netz zu trennen, sollten Sie alle Netzkabel aus der Rückseite des Gerätes, aus der externen Stromversorgung (falls dies möglich ist) oder aus der Wandsteckdose ziehen.

Schutz des Netzkabels • Netzkabel sollten stets so verlegt werden, daß sie nicht im Weg liegen und niemand darauf treten kann oder Objekte darauf- oder unmittelbar dagegestellt werden können.

Wartung • Alle Wartungsmaßnahmen sollten nur von qualifiziertem Servicepersonal durchgeführt werden. Die internen Komponenten des Gerätes sind wartungsfrei. Zur Vermeidung eines elektrischen Schocks versuchen Sie in keinem Fall, dieses Gerät selbst öffnen, da beim Entfernen der Abdeckungen die Gefahr eines elektrischen Schlags und/oder andere Gefahren bestehen.

Schlitze und Öffnungen • Wenn das Gerät Schlitze oder Löcher im Gehäuse aufweist, dienen diese zur Vermeidung einer Überhitzung der empfindlichen Teile im Inneren. Diese Öffnungen dürfen niemals von anderen Objekten blockiert werden.

Litium-Batterie • Explosionsgefahr, falls die Batterie nicht richtig ersetzt wird. Ersetzen Sie verbrauchte Batterien nur durch den gleichen oder einen vergleichbaren Batterietyp, der auch vom Hersteller empfohlen wird. Entsorgen Sie verbrauchte Batterien bitte gemäß den Herstelleranweisungen.

Advertencia

Alimentación eléctrica • Este equipo debe conectarse únicamente a la fuente/tipo de alimentación eléctrica indicada en el mismo. La alimentación eléctrica de este equipo debe provenir de un sistema de distribución general con conductor neutro a tierra. La tercera pata (puesta a tierra) es una medida de seguridad, no puede ser eliminada.

Desconexión de alimentación eléctrica • Para desconectar con seguridad la acometida de alimentación eléctrica al equipo, desenchufar todos los cables de alimentación en el panel trasero del equipo, o desenchufar el módulo de alimentación (si fuera independiente), o desenchufar el cable del receptáculo de la pared.

Protección del cables de alimentación • Los cables de alimentación eléctrica se deben instalar en lugares donde no sean pisados ni apretados por objetos que se puedan apoyar sobre ellos.

Reparaciones/mantenimiento • Solicitar siempre los servicios técnicos de personal calificado. En el interior no hay partes a las que el usuario deba acceder. Para evitar riesgo de electrocución, no intentar personalmente la reparación/ mantenimiento de este equipo, ya que al abrir o extraer las tapas puede quedar expuesto a voltajes peligrosos u otros riesgos.

Ranuras y aberturas • Si el equipo posee ranuras o orificios en su caja/alojamiento, es para evitar el sobrecalentamiento de componentes internos sensibles. Estas aberturas nunca se deben obstruir con otros objetos.

Batería de litio • Existe riesgo de explosión si esta batería se coloca en la posición incorrecta. Cambiar esta batería únicamente con el mismo tipo (o su equivalente) recomendado por el fabricante. Desachar las baterías usadas siguiendo las instrucciones del fabricante.

FCC Class A Notice

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Note: This unit was tested with shielded cables on the peripheral devices. Shielded cables must be used with the unit to ensure compliance.

Extron's Warranty

Extron Electronics warrants this product against defects in materials and workmanship for a period of three years from the date of purchase. In the event of malfunction during the warranty period attributable directly to faulty workmanship and/or materials, Extron Electronics will, at its option, repair or replace said products or components, to whatever extent it shall deem necessary to restore said product to proper operating condition, provided that it is returned within the warranty period, with proof of purchase and description of malfunction to:

USA, Canada, South America, and Central America:

Extron Electronics
1001 East Ball Road
Anaheim, CA 92805, USA

Europe, Africa, and the Middle East:

Extron Electronics, Europe
Beeldschermweg 6C
3821 AH Amersfoort
The Netherlands

Asia:

Extron Electronics, Asia
135 Joo Seng Road, #04-01
PM Industrial Bldg.
Singapore 368363

Japan:

Extron Electronics, Japan
Kyodo Building
16 Ichibancho
Chiyoda-ku, Tokyo 102-0082
Japan

This Limited Warranty does not apply if the fault has been caused by misuse, improper handling care, electrical or mechanical abuse, abnormal operating conditions or non-Extron authorized modification to the product.

If it has been determined that the product is defective, please call Extron and ask for an Applications Engineer at (714) 491-1500 (USA), 31.33.453.4040 (Europe), 65.6383.4400 (Asia), or 81.3.3511.7655 (Japan) to receive an RA# (Return Authorization number). This will begin the repair process as quickly as possible.

Units must be returned insured, with shipping charges prepaid. If not insured, you assume the risk of loss or damage during shipment. Returned units must include the serial number and a description of the problem, as well as the name of the person to contact in case there are any questions.

Extron Electronics makes no further warranties either expressed or implied with respect to the product and its quality, performance, merchantability, or fitness for any particular use. In no event will Extron Electronics be liable for direct, indirect, or consequential damages resulting from any defect in this product even if Extron Electronics has been advised of such damage.

Please note that laws vary from state to state and country to country, and that some provisions of this warranty may not apply to you.

Quick Start Guide — RCP 2000

Step 1

Turn the equipment off and disconnect it from the power source. Make sure that the ISS 108/408 or SGS 408 and all attached devices are turned off and, if applicable, disconnected from the power source.

Step 2

Set the RCP 2000 on a table or other flat surface.


Step 3

SGS Switcher:

Attach one of the RS-232 cables provided with the RCP 2000 between the RS-232 Remote port on the rear panel of the SGS and the To Switcher port on the rear panel of the RCP 2000.

ISS Switcher:

Attach one of the RS-232 cables provided with the RCP 2000 between the RS-232 port on the rear panel of the ISS and the To Switcher port on the rear panel of the RCP 2000; or attach a network cable between the ISS and RCP 2000 rear panel Ethernet ports.



RCP 2000 to ISS connection diagram

Quick Start Guide — RCP 2000, cont'd

NOTE Six sizes of male-to-male RS-232 cables are provided with the RCP 2000, any of which can be used to connect the SGA or ISS switcher's RS-232 port to the RCP 2000's To Switcher (RS-232) port. If you require a length of cable other than what is provided, you can make your own communication cable (see Making an RCP Communication Cable in chapter 2). Additionally, you can connect the RCP 2000 to the ISS via Ethernet using a network cable (not provided).

Step 4

Continue the procedure for installing the ISS 108/408 or SGS 408.

Step 5

Attach power cords and plug the ISS or SGS seamless switcher, the input devices, and the output devices into a grounded AC source.

Attach the power cord to the RCP 2000.

Step 6

Select an input using the RCP 2000 top panel (Program input) buttons. The image should now appear.

Step 7

If the image does not appear, do the following:

- Ensure that all devices are plugged in and receiving power.
- Check the cabling and make adjustments as needed.
- Select a different input to check for an image.

Table of Contents

Chapter 1 • Introduction	1-1
Features	1-2
Chapter 2 • Installation	2-1
Rear Panel Connectors	2-2
Installation	2-2
Application Example	2-4
Making an RCP Communication Cable	2-4
RCP 2000 to ISS 108/408, SGS 408 RS-232 link	2-5
RCP 2000 to ISS 108/408 Ethernet link	2-5
Chapter 3 • Operation	3-1
Top Panel Controls	3-2
Using the Picture Controls	3-5
Adjusting color and tint	3-5
Adjusting contrast and brightness	3-5
Sizing an image	3-5
Centering an image	3-5
Detail adjustments	3-6
Applying and Changing a Switching Effect	3-6
Cuts	3-6
Dissolves	3-7
Changing the duration of a dissolve	3-7
Wipes (SGS only)	3-7
Standard wipe	3-7
Curtain wipe	3-8
Plus wipe	3-8
Square wipe	3-9
Title	3-9
Selecting a wipe and a wipe duration	3-9
Implementing an effect	3-10
Implementing a title	3-11
Resetting the Unit	3-11
Chapter 4 • Remote Control	4-1
Manual IP Setup	4-2
Changing the IP addresses	4-2
Network IP Setup and Control	4-4
Contacting the RCP unit	4-4

Table of Contents, cont'd

Accessing and using the Web pages	4-4
Logon and system status	4-4
Establishing or changing system settings.....	4-5
Firmware upgrade	4-7
File management	4-8
Network Switcher Control	4-9
Accessing network switcher control	4-9
Using network switcher control	4-10
Appendix A • Specifications, Parts, and	
Accessories	A-1
Specifications	A-2
Part Numbers	A-3

All trademarks mentioned in this manual are the properties of their respective owners.

68-792-01 **Rev. C**
03 05



RCP 2000 Remote Control Panel

Chapter One

Introduction

Features

Introduction

The Extron RCP 2000 remote control panel provides complete remote control of a seamless switcher. The RCP controls the input selection, transition effect (cut, dissolve, or wipe), transition duration (automatic or T-bar manual control), and picture controls (color, tint, contrast, brightness, sizing, and centering) that are available on the ISS 108/408 or SGS 408 seamless switcher.

The RCP 2000 offers bi-directional Ethernet communication for the ISS 108/408, and RS-232 communication for both the ISS and the SGS 408. The RCP 2000 allows a switch to occur from either the RCP or the seamless switcher while the other device is being updated.

Features

Comprehensive picture controls — Enable you to adjust the following:

Contrast/Brightness — Adjusts the light intensity and the range of dark and light values of the output.

Centering and sizing — Allow the output to be centered or sized, both horizontally and vertically.

Detail — Adjusts the level of picture sharpness.

Color/Tint — Adjusts the intensity and appearance of the picture colors.

Remote operation — Allow seamless switchers to be operated remotely via Ethernet (Internet or intranet) or RS-232.

Program and preview inputs — Allow you to select the upcoming switch.

Transition controls (Cut, Dissolve, Wipe, and Take) — Control the type of switch that will occur between the preview and program outputs. See *Applying and Changing a Switching Effect* in chapter 3 for descriptions of the transitions controlled by these buttons.

Freeze and Black buttons — Allow you to freeze or blank any input on either the program or the preview.



RCP 2000 Remote Control Panel

Chapter Two

Installation

Rear Panel Connectors

Installation

Application Example

Making an RCP Communication Cable

Installation

Rear Panel Connectors




Figure 2-1 — RCP 2000 rear panel

- ① **AC power connector** — Plug a standard IEC power cord from a 100 to 240 VAC, 50/60 Hz power source into this connector.
- ② **To Switcher port** — This 9-pin female D connector provides for two-way RS-232 serial communications with the SGS or ISS switcher. Connect an RS-232 cable from this port to the switcher's RS-232 port.
- ③ **RS-232 port** — This 9-pin female D connector provides for two-way RS-232 serial communication with the computer to control the RCP 2000.
- ④ **RJ-45 connector** — Connect the RCP 2000 to an ISS 108/408 over an Ethernet LAN using this female RJ-45 connector.
- ⑤ **Reset button** — Use an Extron Tweaker or a small screwdriver to press this recessed button to reset the RCP 2000 unit. See *Resetting the Unit* in chapter 3 for additional information.

Installation

To install and set up the RCP 2000, follow these steps:

- 1 Turn all of the equipment off. Make sure that the ISS 108/408 or SGS 408 and all attached devices are turned off and, if applicable, disconnected from the power source.
- 2 Set the RCP 2000 on a table or other flat surface.

- 3 **SGS Switcher:**
Attach one of the RS-232 cables provided with the RCP 2000 between the RS-232 Remote port on the rear panel of the SGS and the To Switcher port on the rear panel of the RCP 2000.

ISS Switcher:

Attach one of the RS-232 cables provided with the RCP 2000 between the RS-232 port on the rear panel of the ISS and the To Switcher port on the rear panel of the RCP 2000; or attach a network cable between the ISS and RCP 2000 rear panel Ethernet ports.

- 4 Continue the procedure for installing the ISS 108/408 or SGS 408.
- 5 Attach power cords and plug the ISS/SGS seamless switcher, the input devices, and the output devices into a grounded AC source.
- 6 Attach the power cord to the RCP 2000.
- 7 Select an input using the RCP 2000 top panel Program input buttons. The image should now appear.
- 8 If the image does not appear, do the following:
 - Ensure that all devices are plugged in and receiving power.
 - Check the cabling and make adjustments as needed.
 - Select a different input to check for an image.

Application Example

The following diagram is an example of the RCP 2000 connected to an ISS 408, along with various input and output devices.




Figure 2-2 — RCP 2000 application example

Making an RCP Communication Cable

The RCP 2000 communicates with the SGS 408 via RS-232. Communication between the RCP 2000 and the ISS 108/408 is via RS-232 or Ethernet. You are provided with six RS-232 cables of different lengths. If you need an RCP communication cable that is a different length from those that are provided, use the following guidelines to make your own cable.

RCP 2000 to ISS 108/408, SGS 408 RS-232 link

Both ends of the RS-232 cable must be terminated with a 9-pin male D connector. See figure 2-3 for RS-232 pin assignments.

Pin	RS-232	Function
1	—	Not used
2	TX	Transmit data
3	RX	Receive data
4	—	Not used
5	Gnd	Signal ground
6	—	Not used
7	—	Not used
8	—	Not used
9	—	Not used




Figure 2-3 — RCP 2000 RS-232 pinouts

RCP 2000 to ISS 108/408 Ethernet link

The RCP 2000 can communicate with the ISS 108/408 via an Ethernet link using the RJ-45 connector on both the RCP and the ISS. The RJ-45 connector is illustrated in the following diagram. The RCP 2000 can be connected to the ISS through Ethernet either directly or indirectly, as described on the next page.




Figure 2-4 — RCP 2000 RJ-45 connector wiring

- When connecting the RCP 2000 *directly* (no intermediate device present, such as a network hub) to the ISS 108/408, you must use a **crossover cable**. See the table on the next page for RJ-45 crossover cable connections.

RJ-45 Ethernet Crossover Cable

RCP 2000 end			Intermediate hub, etc., end		
Pin	Wire color	Signal	Pin	Wire color	Signal
1	White-orange	Transmit +	3	White-orange	Receive +
2	Orange	Transmit -	6	Orange	Receive -
3	White-green	Receive +	1	White-green	Transmit +
6	Green	Receive -	2	Green	Transmit -
4	Blue	N/A	4	Blue	N/A
5	White-blue	N/A	5	White-blue	N/A
7	White-brown	N/A	7	White-brown	N/A
8	Brown	N/A	8	Brown	N/A

- When connecting the RCP 2000 *indirectly* (intermediate device present, such as a network hub) to the ISS 108/408, you must use a **patch** (straight-through) cable. See the table below for RJ-45 patch cable connections.

RJ-45 Ethernet Patch Cable

RCP 2000 end			SGS 408, ISS 108/408 end		
Pin	Wire color	Signal	Pin	Wire color	Signal
1	White-orange	Transmit +	1	White-orange	Receive +
2	Orange	Transmit -	2	Orange	Receive -
3	White-green	Receive +	3	White-green	Transmit +
4	Blue	N/A	4	Blue	N/A
5	White-blue	N/A	5	White-blue	N/A
6	Green	Receive -	6	Green	Transmit -
7	White-brown	N/A	7	White-brown	N/A
8	Brown	N/A	8	Brown	N/A



RCP 2000 Remote Control Panel

Chapter Three

Operation

Top Panel Controls

Using the Picture Controls

Applying and Changing a Switching Effect

Resetting the Unit

Top Panel Controls




Figure 3-1 — RCP 2000 top panel

- ① **XLR lamp socket** — Allows a Littlite® flexible gooseneck lamp to be connected for low intensity illumination of the control panel.
- ② **Lamp dimmer control** — Rotating this knob adjusts the intensity of the lamp (①).
- ③ **Program input selection buttons** — Allow the system operator to view the image switch as it happens. The button lights for the currently selected program input.

Freeze — Locks the output display to the image that is currently displayed on the program output.

 - When a program image is frozen, a switch can still occur. When the output is switched, the freeze command stays in effect.
 - To unfreeze the image, press the Freeze button.
 - If an image is frozen when a different input is selected, or if the unit loses power, the image unfreezes.

Black — Causes a black screen to be displayed. The black screen can be switched by applying a cut or another effect. A black input cannot be frozen.

1 – 12 — Selects the corresponding input to be displayed. Normally, you will not use these buttons during a show. If a program input selection button is pressed, the resulting switch is not seamless.

- ④ **Preview input selection buttons** — Allow the system operator to view the image before switching it to the program output. The button for the currently selected preview input lights.

Freeze — Locks the preview image that is currently selected.

 - When a preview image is frozen, a switch can still occur. When the output is switched, the freeze command stays in effect.
 - To unfreeze the image, press the Freeze button.
 - If an image is frozen when a different input is selected, or if the unit loses power, the image unfreezes.

Black — Causes a black screen to be selected for preview. The black screen can be switched by applying a cut or another effect. The black input cannot be frozen.

1 – 12 — Allow you to select the preview input device. The button is lit while the input is active.

- ⑤ **Transmit and Receive LEDs** — These LEDs flicker whenever Ethernet data is being transmitted or received by the RCP 2000. The data traffic is between the RCP and the SGS 408 or the ISS 108/408.
- ⑥ **Menu adjustment knob** — Allows adjustment of menu selections. See *Applying and Changing a Switching Effect*, later in this chapter.
- ⑦ **LCD display** — Displays status information and menu screens.
- ⑧ **Switching effect buttons** — Control the type of switch that will occur between program and preview inputs. Unless otherwise indicated, the buttons affect both the ISS and SGS switchers.

Cut button — Initiates an immediate seamless switch between the program and preview images.

Dissolve button — Causes the program input to fade out while the preview input fades in. The dissolve duration is adjustable.

Wipe button (SGS only) — Causes the preview image to appear to unroll over the program image horizontally or vertically. The different wipe effects include standard, curtain, plus, square, and title window.

Take button — Initiates the switch selected through the switching effect buttons.

For further information, see *Applying and Changing a Switching Effect*, later in this chapter.

- ⑨ **T-bar controller** — Allows you to manually override the duration of an effect by pulling on the T-bar handle. See *Applying and Changing a Switching Effect*, later in this chapter.
- ⑩ **Picture control buttons** — Allow you to make adjustments to the picture for either the program or the preview output. The five control buttons control color and tint, contrast and brightness (Cont/Bright), sizing (Size), centering (Center), and detail. These buttons light when pressed. See *Using the Picture Controls*, later in this chapter.

After an input is selected, press the desired picture control button, then rotate the appropriate encoder knob ⑪ or ⑫ while viewing the output display. You can adjust the centering, sizing, and detail horizontally or vertically using the horizontal (H) and vertical (V) adjustment knobs. Contrast and color are adjusted using the H knob; brightness and tint are adjusted using the V knob.

- ⑪ **Horizontal adjustment knob (H)** — Allows horizontal adjustments to the centering, sizing, and detail picture controls. Contrast and color are also adjusted using this knob. After selecting an input, press the desired picture control button and rotate this knob to make the adjustment.
- ⑫ **Vertical adjustment knob (V)** — Allows vertical adjustments to the centering, sizing, and detail picture controls. Brightness and tint are also adjusted using this knob. After selecting an input, press the desired picture control button and rotate this knob to make the adjustment.

Using the Picture Controls

The picture controls allow you to adjust the centering, size, detail, contrast/brightness, and color/tint of the preview image.

Adjusting color and tint

To adjust the color and tint of an image, do the following:

1. Press and release the Color/Tint button. The button lights.
2. To change the color, rotate the H adjustment knob.
3. To change the tint, rotate the V adjustment knob.

Adjusting contrast and brightness

To adjust the contrast and brightness of an image, do the following:

1. Press and release the Cont/Bright button. The button lights.
2. To change the contrast, rotate the H adjustment knob.
3. To change the brightness, rotate the V adjustment knob.

Sizing an image

To adjust the image size, do the following:

1. Press and release the Size button. The button lights.
2. To adjust the vertical size (height), rotate the V adjustment knob.
3. To adjust the horizontal size (width), rotate the H adjustment knob.

Centering an image

To adjust the image centering, do the following:

1. Press and release the Center button. The button lights.
2. To adjust the vertical centering, rotate the V adjustment knob.
3. To adjust the horizontal centering, rotate the H adjustment knob.

Detail adjustments

To apply a horizontal or vertical filter to improve the sharpness of an image, do the following:

1. Press and release the Detail button. The button lights.
2. Various levels of detail adjustment are available, depending on the input signal format.
 - To change the vertical filter (if available), rotate the V adjustment knob. Choose the filter that provides the most improvement to the image detail.

NOTE *The availability of some filters depends on the type of switcher that is connected. Check your switcher's user manual for to find out if this feature is supported.*

- To change the horizontal filter (if available), rotate the H adjustment knob. Choose the filter that provides the sharpest image.

Applying and Changing a Switching Effect

You can switch the program and preview inputs using a variety of switching effects. For a description of each effect, and the technique to implement it, see the instructions for the effect in this section. Unless otherwise indicated, the effects are available for both the ISS and SGS switchers.

Cuts

A cut seamlessly replaces the program image with the preview image. No effect is applied to the switch. As soon as the Cut button is pressed, the switch occurs.

To switch using a cut, do the following:

1. Press the preview input button that corresponds to the input that you want to switch to.
2. Press the Cut button. The seamless switch takes effect immediately, and the preview image becomes the new program image.

Dissolves

A dissolve causes the program image to fade out while the preview image fades in (figure 3-2). See *Implementing an effect*, later in this chapter, for information on how to implement a dissolve.



Figure 3-2 — A dissolve effect

Changing the duration of a dissolve

To change the duration of a dissolve, do the following:

1. Press the Dissolve button. The Dissolve button lights.
2. Rotate the Adjust knob next to the buttons. A duration menu appears on the LCD screen, showing the current duration selected for the dissolve. Select any dissolve duration time from 0.2 to 5.0 seconds.

Wipes (SGS only)

The different types of wipes available on the RCP 2000 are described in this section.

Standard wipe

A **standard wipe** causes the preview image to appear to unroll over the program image horizontally or vertically. A standard wipe can have either hard (sharp) or soft (fuzzy) edges.

The preview image can have the following transitions (see figure 3-3):

- From left to right
- From right to left
- From top to bottom
- From bottom to top



Figure 3-3 — Standard wipe transitions

Curtain wipe

A **curtain wipe** causes the preview image to appear to unroll over the program image in two directions simultaneously. A curtain wipe can have either hard (sharp) or soft (fuzzy) edges. The preview image can have the following transitions (figure 3-4):

- In from the left and right edges of the screen to the center of the screen
- Out from the center of the screen to the left and right edges of the screen
- In from the top and bottom edges of the screen to the center of the screen
- Out from the center of the screen to the top and bottom edges of the screen.



Figure 3-4 — Curtain wipe effects

Plus wipe

A **plus wipe** causes the preview image to appear to unroll over the program image in one of two transitions (figure 3-5):

- Starting in all four corner of the screen and moving in to the center of the screen.
- Starting at the center of the screen and moving out to the corners of the screen.



Figure 3-5 — Plus wipe effects

Square wipe

A **square wipe** causes the preview image to appear to unroll over the program image in one of two transitions (figure 3-6):

- Starting at all four edges of the screen and moving in to the center of the screen.
- Starting at the center of the screen and moving out to the edges of the screen.



Figure 3-6 — Square wipe effects

Title

A **title** causes a predefined box in the program image to dissolve to reveal the preview image (figure 3-7). The effect is as if the preview image were located behind the program image, and a window in the program image opens to show the preview image. When the effect ends, the preview image has disappeared, and the program image is again intact.

NOTE *The title box can be sized and centered anywhere on the screen. See chapter 3 of the SGS 408 User's Manual for more information.*




Figure 3-7 — A title effect

Selecting a wipe and a wipe duration

To select a wipe, do the following:

1. Press and hold the Wipe button. The Wipe button lights and a wipe menu appears on the LCD screen, showing the currently selected wipe.
2. Rotate the Adjust knob next to the buttons and select a wipe from the 21 choices presented in sequence (see figure 3-8 on the next page).




Figure 3-8 — Available wipes

To select the duration of a wipe, do the following:

1. Press and release the Wipe button. The Wipe button lights and a duration menu appears on the LCD screen, showing the current duration selected for the wipe.
2. Rotate the Adjust knob next to the buttons, and select any wipe duration from 0.2 to 5.0 seconds as indicated on the LCD screen.




Figure 3-9 — Wipe duration

Implementing an effect

To implement an effect after it has been set up on the RCP 2000, follow these steps. (For a title effect, see *Implementing a title*, on the next page.)

1. Press the preview input button to display the preview image on the preview monitor.
2. Press the Effect button for the desired effect. (If the button is already lit, you do not need to press it.)
3. When you want the effect to occur, press the Take button. The Take button lights, the effect occurs during the time specified by the duration, and the Take button light turns off.

- OR -

If you want to control the effect by hand, move the T-bar at the desired rate.

Implementing a title

To implement a title, do the following:

1. Press the preview input button to display the preview image on the preview monitor.
2. Press the Effect button that has been selected for the title. (If the button is already lit, you do not need to press it.)
3. When you want the title to begin, press the Take button. The portion of the program image dissolves to reveal the title. The Take light remains on.
4. When you want to end the title, press the Take button again. The title dissolves during the time specified by the duration, and the Take button light turns off.

Resetting the Unit

There are three reset modes available by using the Reset button (item ⑤, page 2-2) on the rear panel. The Reset switch is recessed, so use of a pointed stylus, ballpoint pen, or Extron Tweaker is suggested.

CAUTION Review the reset modes carefully. Use of the wrong reset mode may result in unintended loss of flash memory programming, reassignment of ports, or unit reboot.



Mode 1 — Pressing and **holding** the Reset button until the front panel LCD display shows “Reset Mode 1” (3 seconds), then immediately pressing the button momentarily (for less than one second), causes all events to stop running. The LCD screen displays “Unit reset” when the Mode 1 reset is complete.

NOTE Nothing happens if the second, momentary press does not occur within one second.



Mode 2 — Pressing and **holding** the Reset button until the front panel LCD display shows “Reset Mode 2” (5 seconds), then immediately pressing the button momentarily (for less than one second) erases all user flash memory, resets ports to default conditions, and reboots the unit. The LCD screen displays “Unit reset” when the Mode 2 reset is complete.

NOTE Nothing happens if the second, momentary press does not occur within one second.

Operation, cont'd

RESET
MODE 3

Mode 3 — Pressing and **holding** the Reset button until the front panel LCD display shows “Reset Mode 3” (10 seconds), then immediately pressing the button momentarily (for less than one second) causes an absolute system reset to factory defaults. The LCD screen displays “Unit reset” when the Mode 3 reset is complete.

NOTE *Nothing happens if the second, momentary press does not occur within one second.*



RCP 2000 Remote Control Panel

4 Chapter Four

Remote Control

Manual IP Setup

Network IP Setup and Control

Network Switcher Control

Manual IP Setup

The RCP 2000 unit ships with default server (ISS) and client (RCP) IP addresses, as well as Subnet Mask and Gateway Address, already set. These default IP addresses can be changed to conform to the IP address format required for your network or designated by your network administrator.

Changing the IP addresses

To change the IP addresses:

1. Press the four effects buttons (Wipe, Dissolve, Cut, and Take) simultaneously until the LCD screen shows the RCP unit's MAC address (xx-xx-xx-xx-xx-xx), and the Cut button lights.

```
XX-XX-XX
XX-XX-XX
```




Figure 4-1 — Setting up for an IP address change

2. Press the Take button. The Cut button stays on, the Take, Cont/Bright, Size, and Center buttons light, and the Color/Tint button blinks. The client IP address (IP) is visible on the LCD screen.
3. Using the H adjust knob, change the first block of the IP address. Then do one or more of the following:
 - Press the Cont/Bright button and use the H adjust knob to change the second block of the address.

```
I 192.168.
P 128.128
```

- Press the Size button and use the H adjust knob to change the third block of the address.
 - Press the Center button and use the H adjust knob to change the fourth block of the address.
4. Press the Take button again. The server IP address (SI) is now visible on the LCD screen. Repeat step 3 to change the server IP address.
 5. Press the Take button again. The Subnet Mask (SM) is now visible on the LCD screen. Repeat step 3 to change the Subnet Mask.
 6. Press the Take button again. The Gateway (GM) is now visible on the LCD screen. Repeat step 3 to change the Gateway.
 7. Press the Detail button to exit and to save all address changes.

```
S 192.168.
M 128.128
```

```
S 255.255.
M 255.128
```

```
G 255.255.
M 255.255
```




Figure 4-2 — Making the IP address change

Network IP Setup and Control

Once the IP addresses have been changed, if required, you can contact and control the RCP 2000 by using Web pages that are resident, in firmware, on the RCP unit.

Contacting the RCP unit

The resident Web pages are the primary means of communication with, and control through, the RCP unit. The Web pages are accessed via a Web browser, such as Internet Explorer (version 5.5 or higher).

The PC that is used to access the Web server must have a connection in common with the RCP unit. For example, if the unit is connected to your local intranet, the PC that is used to access the unit must also be connected to your local intranet. Similarly, if the unit is connected only to the Internet, the PC that is used to access the unit must have an Internet connection.

When your browser accesses the RCP unit, if you have established passwords for the unit you are shown a Password window (except when you initially access the Web page, because at that time no passwords have been established). Your level of control over the unit depends on the password you enter on this password screen. If you enter the administrator password, you are permitted to configure or change all settings. If you enter a user password, you are permitted only to control A/V devices and to view status.

Accessing and using the Web pages

Logon and system status

1. Double-click the Web browser icon on your Windows desktop to launch your Web browser.
2. Enter the IP address of the unit (see *Changing the IP addresses*, earlier in this chapter) in the address field at the top of the screen, and press the Enter key. The Password window is opened if a password has been set. (This does not happen the first time you access the interface, because no password is set at the factory).
3. Enter the appropriate password (if required). The System Status page opens (figure 4-3), showing the current IP address and other settings of the unit.
4. Click Log Off on the left side of the screen to exit the system.

Establishing or changing system settings

The System Settings screen is used to review the configuration of the RCP unit and to access the Web pages for the controlled switcher. The System Settings screen can be accessed from the initial (System Status) screen.




Figure 4-3 - System Status screen

To change system settings:

1. Select the Configuration tab. The System Settings screen (figure 4-4) opens.

Figure 4-4 — System Settings screen

2. Make changes to the IP Settings, Date/Time settings, etc., as necessary.
3. Click the Submit button to enter the changes, or click the Cancel button to revert to the previous settings.

CAUTION Be aware that changing the IP address, Subnet mask, or other IP Settings could affect your ability to contact the RCP unit.

Firmware upgrade

Also available on the Configuration tab is the Firmware Upgrade screen. This screen is used to check and, if necessary, upgrade the firmware for the RCP unit. To check and/or upgrade the firmware, follow these steps:

1. From the Configuration tab, click on *Firmware Upgrade* from the menu column on the left side of the screen. The Firmware Upgrade screen (figure 4-5) is opened.

Figure 4-5 — Firmware Upgrade screen

2. Use the Browse button to access Extron's Website (www.extron.com), and select the product category for your RCP unit.
3. Review the available firmware versions and compare them to the Current Firmware Version shown on the Firmware Upgrade screen.
4. If a newer firmware version is available, select and highlight the file (it must have the file extension .S19), then click Upload. The new firmware is uploaded to your RCP unit.

CAUTION Be aware that uploading the incorrect file may cause your RCP unit to stop functioning.

NOTE The original factory-installed firmware is permanently available on the RCP 2000. If the attempted upload of new firmware fails for any reason, the RCP 2000 reverts to the factory-installed firmware.

File management

The File Management screen is used to upload new files (for custom or updated Web pages) to the RCP unit and to delete existing files from the unit. The File Management screen can be accessed from the initial (System Status) screen.

To upload new files or delete existing files:

1. Select the File Management tab. The File Management screen (figure 4-6) opens.




Figure 4-6 — File Management screen

2. To upload new files to the RCP unit, click the Browse button. Find the file(s) on the control PC, networked computer, or networked server, and select (highlight) the file(s).
3. Click the Upload File button to upload the file to the RCP unit. Note the file name restrictions mentioned in the instructions.
4. To delete a file from the RCP unit, find the file on the file list and select the Delete check box. When you are ready to delete the selected file(s), click the Delete Files button.

Network Switcher Control

In addition to network configuration, passwords, file management, and similar tasks, the Web server can also be used to control an ISS 108/408.

Accessing network switcher control

To access network switcher control:

1. Double-click the Web browser icon on your Windows desktop to launch your Web browser.
2. Enter the IP address of the RCP unit (see *Changing the IP addresses*, earlier in this chapter) in the address field at the top of the screen, and press the Enter key. The Password window is opened if a password has been set. (This does not happen the first time you access the interface, because no password is set at the factory).
3. Enter the appropriate password (if required). The System Status page opens (figure 4-3), showing the current IP address and other settings of the unit.
4. Select the Configuration tab. The System Settings screen (figure 4-4) opens.
5. At the bottom of the System Settings screen, in the Controlled Switcher area, enter the IP address of the switcher to be controlled (in the IP Address field); then click the Submit button.
6. Once the IP address of the switcher has been set, click the Control button. The switcher Control screen (figure 4-7) opens.

NOTE *I/O Configuration should be completed in accordance with the user's manual for your switcher. System Configuration and File Management information is also available in the user's manual specific to your switcher; however, the information presented in the Establishing or changing system settings and File Management sections of this manual are generally applicable.*




Figure 4-7— ISS Control screen

Using network switcher control

To use network switcher control, follow these steps:

1. Set the level of control desired: video/audio, video only, or audio only.
2. Select the Program (output) that you want to switch.
3. Select the Preview (input) that you want to switch to.
4. Set the parameters of the switch (for example, Dissolve Speed or RGB Delay), and click the appropriate button to execute the switch (e.g., Cut, Dissolve, etc.).

- OR -

Click the button for the desired effect (for example, Black/Mute, Freeze, Test Pattern, or Blue Screen Mode) for the output.

NOTE To compare Program (output) and Preview (input) scan rates, click View Program (or Preview) Scan Rate.

NOTE If you require a test pattern on either the Program or the Preview, select the desired test pattern from the drop-down menu; and select either the Program or the Preview check box in the Test Pattern section of the screen.

For a more complete description of seamless switching and the options available for each switcher, refer to the user's manual for your specific switcher.



Appendix

Specifications, Parts, and Accessories

Specifications

Part Numbers

Specifications, Parts, and Accessories

Specifications

Control/remote — control panel

Serial control port	RS-232, 9-pin female D connector
Baud rate and protocol	9600, 8-bit, 1 stop bit, no parity
Serial control pin configurations	2 = TX, 3 = RX, 5 = GND
Ethernet control port	1 RJ-45 female connector
Ethernet data rate	10/100Base-T, half/full duplex with autodetect
Ethernet protocol	ICMP (ping), TCP/IP, Telnet
Program control	Extron's control program for Windows®, Extron's Simple Instruction Set™ – SIS™, Microsoft Explorer, Telnet

General

Power	100 VAC to 240 VAC, 50/60 Hz, 60 watts, internal, autoswitchable
Temperature/humidity	Storage -40° to +158°F (-40° to +70°C) / 10% to 90%, non-condensing Operating +32° to +122°F (0° to +50°C) / 10% to 90%, non-condensing
Rack mount	No
Enclosure type	Metal
Enclosure dimensions	5.25" H x 16" W x 11.5" D 13.3 cm H x 40.6 cm W x 29.2 cm D (Depth excludes connectors and knobs.)
Product weight	15 lbs (6.8 kg)
Shipping weight	22 lbs (10 kg)
Vibration	ISTA/NSTA 1A in carton (International Safe Transit Association)
Listings	UL, CUL
Compliances	CE, FCC Class A, VCCI, AS/NZS, ICES
MTBF	30,000 hours
Warranty	3 years parts and labor

NOTE Specifications are subject to change without notice.

Part Numbers

Extron Part	Part Number
RCP 2000	60-571-01
RS-232 male-male cable – 2' (.61 m)	26-434-01
RS-232 male-male cable – 4' (1.22 m)	26-434-02
RS-232 male-male cable – 25' (7.6 m)	26-434-07
RS-232 male-male cable – 50' (15.2 m)	26-434-08
RS-232 male-male cable – 100' (30.5 m)	26-434-10
RS-232 male-male cable – 250' (76.2 m)	26-434-13
<i>RCP 2000 User's Manual</i>	

Specifications, Parts, and Accessories, cont'd