

vnmatrix

STREAMING ENCODER/DECODER



USER GUIDE

VN-MATRIX USER GUIDE
Part No. I458GB issue 6 (24/04/2008)

Copyright © 2008 Electrosonic Ltd.
All rights reserved.

No part of this documentation may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, without the prior written permission of Electrosonic Ltd.

The information in this documentation is supplied without warranty of any kind, either directly or indirectly, and is subject to change without prior written notice. Electrosonic, its employees or appointed representatives will not be held responsible for any damages to software, hardware, or data, howsoever arising as a direct or indirect result of the product(s) mentioned herein.

Issued by:

Product Support Team,
Electrosonic Ltd.,
Hawley Mill,
Hawley Road,
Dartford,
Kent,
DA2 7SY,
United Kingdom.

Documentation written and designed by Andrew M. Bailey.
Additional information by Robert S. Simpson and Glen Towndrow.

Printed in the United Kingdom.

IMPORTANT SAFETY MARKINGS

The following symbols are used throughout this User Guide to advise you of important instructions:



This symbol warns the presence of a voltage of sufficient magnitude to cause a severe or fatal electric shock. Follow the appropriate instructions carefully to avoid the risk of injury.



This symbol indicates an important instruction for the correct and safe installation, operation or maintenance of your VN-MATRIX system. Failure to comply with such instructions may result in injury to personnel or damage to the VN-MATRIX hardware.



This product conforms with the protection requirements of the EC Directive 89/336/EEC (relating to Electromagnetic Compatibility) and EC Directive 73/23/EEC (relating to Low Voltage) by application of the following standards:

EN 55022:1994 Class B; EN 55024:1994 Class B; EN60950:2000

Provided that:

- The product is used in accordance with the manufacturer's instructions.
- The product is not connected to any peripheral equipment that is not CE marked.



This product has been tested by Underwriters Laboratories Inc.® (file no. E163058) and found to be fully compliant with the following safety standards:

UL 60950-1:2003

Information Technology Equipment Safety - Part 1: General Requirements

CSA C22.2 No. 60950-1-03

Information Technology Equipment Safety - Part 1: General Requirements



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Contents

SECTION 1:	9
Introduction	9
What is VN-MATRIX?	10
Firmware Version	10
Extended Functionality	10
Functional Overview	11
Encoder / Source Compatibility	11
Decoder / Display Capability	11
Control Capability	12
Source Control	12
System Setup & Configuration	12
Integrated Web Management System	12
Remote Control	12
Network Requirements	13
Example System Application	14
Data Transport Methods	15
Multicast RTP	16
Unicast RTP	17
Unicast TCP	18
Front Panel Features	19
Indicators	19
Reset Button	19
Rear Panel Features	20
Power Supply Input	20
Network Connectors	20
Keyboard Connectors	20
Mouse Connectors	20
Monitor Connectors	20
Serial I/O Connectors	20
Accessories	21
Supplied Accessories	21
Optional Accessories	21
SECTION 2:	23
Installation & Basic Setup Procedures	23
Choosing a Suitable Location	24
Environmental Requirements	25
Orientation	25
Temperature	25
Ventilation	25
Humidity & Water	25
Rack-mount Requirements	26
Mounting & Support	26
Ventilation	26
Mains Supply	26
Mains Power Connection (via PSU)	27
Supply Requirements (for PSU)	27

Mains Power Cord (for PSU).....	28
Power-up Procedure.....	28
Fitting a Mains Plug.....	29
Wiring Details.....	29
External Supply Protection.....	30
Fused Plugs (UK-style).....	30
Unfused Plugs or Hard-wired	30
Setup and Connection Procedure.....	31
Network Communications Setup.....	32
Connections	35
Supplied Cables.....	35
Network Connection	36
Connecting a Digital Source	37
Connecting an Analog Source	38
Connecting a Digital Display.....	39
Connecting an Analog Display	40
 SECTION 3:.....	 41
System Configuration.....	41
 The VN-MATRIX Web Interface.....	 42
Accessing the Web Interface	43
The Device List Page	44
On-line Help.....	45
Interface Timeout & Logging Out.....	45
Update Button and Save Tab	45
Configuring a VN-MATRIX as an Encoder (source)	46
Additional Setup for Audio.....	48
Additional Information for Encoder Setup	48
Input Mode.....	49
EDID Options.....	49
Identify Mode	49
Device Mode.....	50
Audio Status	50
Advanced Setup Options.....	50
Configuring a VN-MATRIX as a Decoder (display)	51
Additional Information for Decoder Setup	54
Identify Mode	54
No Data Splash Mode	54
Device Mode.....	54
Advanced Setup Options.....	55
Troubleshooting	56
Display Checkup	57
Source Checkup.....	58
System Checkup	59
Controller Checkup.....	60
 SECTION 4:.....	 61
Advanced Setup Procedures	61
 Encoder Set Up.....	 62
Advanced Source Setup	63
Video Setup Page.....	64
Fine-Tuning a Source (manual overrides).....	65
Creating a Custom Input Mode.....	66

Managing Compression & Bandwidth Settings.....	69
Bandwidth (source) Page	70
Quality Control Settings.....	71
Bandwidth Management Settings.....	72
Audio Compression	73
Decoder Set Up.....	74
Setting Optimum Playback Delay.....	75
Bandwidth Monitoring Page.....	76
Adjusting the Playback Delay	77
Creating a Custom Output Mode	78
The Cloning Method	79
The CVT/GTF Method	80
System Set Up	81
Changing User Login Passwords.....	81
Upgrading Device Firmware.....	82
Changing a Device Licence	85
 SECTION 5:.....	 86
Serial Transport & Control Methods.....	86
 Overview	 87
Data Stream Mode.....	87
Passthrough Mode.....	88
Remote Control Mode	89
Setting-up a Serial Data Stream	90
Setting-up a Serial Passthrough Group	91
Setting-up a Remote Control Group.....	92
Serial / Telnet Commands.....	93
Control Session Commands.....	93
Device Commands	94
Response Messages	95
 SECTION 6:.....	 96
Remote Keyboard & Mouse Operation	96
 Overview	 97
 SECTION 7:.....	 98
Technical Data	98
 VN-MATRIX Hardware	 99
Mechanical Data.....	99
Operating Conditions.....	99
Power Supply	99
Connectors	100
Keyboard/Mouse (PS/2)	100
Digital Audio I/O (SPDIF IN and OUT)	100
DVI Input (IN).....	101
DVI Output (OUT).....	102
Network (I and II)	103
RS-232 Serial I/O (COM1 and COM2)	104

Serial Interface – Quick Reference	105
COM2 Port Settings	105
Login Procedure	105
Command Options	105
Telnet Interface – Quick Reference	106
Starting Telnet	106
Login Procedure	106
Web Interface – Quick Reference	107
Menu Structure	107
Login Page	108
Device List Page	109
Accounts Page	110
Device Page	111
License Page	113
Serial Page	114
Upgrade Page	115
Display Page	116
Format Page	117
Bandwidth Page (display)	118
Configure Page	120
Video Setup Page	122
Bandwidth Page (source)	123
 APPENDIX A:	 124
Guide to IP Addressing	124
What is an IP Address?	125
Private & Public Address Ranges	125
Multicast Address Range	125
Choosing IP Addresses	126
Subnet Mask	126
Using the 'Ping' Utility to Test Communications	127
Response Messages	127
 APPENDIX B:	 128
Understanding Network Performance	128
Network Characteristics	129
Data Packets/Frames	129
Nodes, Switchers & Routers	130
Protocols	131
 APPENDIX C:	 133
Browser Configuration	133
Internet Explorer (v6 or above)	134
Mozilla (v1.3 or above)	136

SECTION 1:

Introduction

What is VN-MATRIX?

VN-MATRIX is used to distribute RGB video/graphics from a source computer (or similar graphical device) across an IP network to one or more viewing stations.

An RGB signal is captured/acquired by a VN-MATRIX unit and encoded in to a TCP or RTP data stream for transport across a local area or wide area network. Elsewhere on the network another VN-MATRIX unit can decode the stream back into an analog RGB or digital (DVI) signal, suitable for display on a wide range of display devices.

In addition to an RGB signal, the VN-MATRIX can provide cross-network transport of:

- Digital Audio (SPDIF), and
- Serial Data (RS-232).

NOTE: *Digital audio can be used to accompany a video/graphics source. VN-MATRIX cannot transport an 'audio only' signal.*

RS-232 serial data can be distributed between VN-MATRIX units unidirectionally as part of the source stream, or bi-directionally independent of any source streams. A VN-MATRIX can also be configured to accept serial remote control commands allowing simple changes to be made to system operation.

Firmware Version

This user guide is based on v3.3c firmware. You can check for newer firmware releases and user guide updates by visiting our web site at www.electrosonic.com/support.

HINT: *To check which version of firmware is currently installed, login to the web interface (see page 41) and go to the Upgrade page (see page 82).*

Extended Functionality

Support for the following extended functions has been introduced for firmware v3.0 and above:

- **Scaling** which allows up/down scaling of sources to suit the target display. By default, sources can only be displayed at their native resolution.
- **Whiteboard** which allows live text and pointer interaction between users of both the local and remote displays.
- **Recorder** which allows recording and playback of source, whiteboard and RS-232 data streams.

By default, these extended functions are disabled and can only be enabled by the purchase and installation of a special license key. Please contact your Electrosonic supplier or agent for details.

These functions are not documented in this user guide.

Functional Overview

The VN-MATRIX can be configured to operate in one of two modes:

- As an **encoder** to encode a source and stream it across a network,
- As a **decoder** to decode a VN-MATRIX data stream from a network.

Therefore, any VN-MATRIX system will comprise at least two devices, one configured as an encoder and the other as a decoder. However, multiple encoders and decoders can co-exist on the same network.

On a given network any decoder has the ability to display the source provided by any encoder.

Encoder / Source Compatibility

As an encoder the VN-MATRIX is compatible with both digital (DVI) and analog (RGB) graphics sources up to UXGA resolution (1600 x 1200 @ 60Hz, 24-bit color). See page 101 for a list of standard supported sources.

The VN-MATRIX incorporates advanced image acquisition circuitry which can auto-detect a wide range of source types without the need for any additional setup.

For specialist or non-standard source formats, user customizable source modes can be created using the Web Interface. See page 66 for further details.

HINT

The VN-MATRIX provides Analog-to-Digital or Digital-to-Analog conversion via its monitor connections. Therefore, it is possible to use a digital monitor with an analog source and vice versa.

Decoder / Display Capability

As a decoder the VN-MATRIX is compatible with both digital (DVI) and analog (RGB) graphics sources up to UXGA resolution (1600 x 1200 @ 60Hz, 24-bit color)*. See page 102 for a list of standard supported sources.

NOTE: *By default, sources are displayed at their native resolution and format. Support for source scaling existing within firmware v3.0 and above but must be enabled by a special license key.*

Control Capability

Source Control

Loop-through connections are provided on the VN-MATRIX for the source computer keyboard and mouse. Local keyboard and mouse control of the source computer is fully maintained while connected to the VN-MATRIX. In addition, keyboard and mouse functions can be remotely controlled from the viewing station.

System Setup & Configuration

Low level communications setup of the VN-MATRIX is achieved using a serial data link to the COM1 port. High level configuration is achieved via the network using the Integrated Web Management System (see below).

Integrated Web Management System

VN-MATRIX incorporates an Integrated Web Management System (Web Interface for short). This allows any VN-MATRIX unit on a network to be configured via a PC/laptop (on the same network), using a standard web browser (*e.g.* Internet Explorer, Netscape Navigator, Opera).

One VN-MATRIX unit on the network must be designated as a 'controller'. This unit acts as a server for the Web Interface and also holds a database of all VN-MATRIX devices on the network.

Any VN-MATRIX unit, whether it is configured as an encoder or decoder, can be used as a controller.

The Web Interface includes a full on-line help system.

Remote Control

RS-232 serial data can be routed between selected VN-MATRIX units, for example to provide remote control of a source.

In addition, serial commands can be input to a VN-MATRIX and routed to the controller to allow basic control of system operation, *e.g.* to change source selection on displays, compression settings, or enabling and disabling devices.

Network Requirements

VN-MATRIX uses highly efficient compression algorithms to minimize the amount of data needed to be transported across the network.

It is, however, crucial to the effective operation of VN-MATRIX that sufficient data throughput can be achieved, especially where multiple sources are being encoded.


The efficiency of a network will be directly affected by the speed and configuration of each element within its infrastructure, *e.g.* switchers and routers. VN-MATRIX will achieve optimum transmission results over a dedicated 1Gbps network (Gigabit Ethernet).

For more general information on networks and network performance, please refer to Appendix B on page 128.

Example System Application

The diagram below shows an example system application utilizing eight VN-MATRIX units. Four are configured as encoders (sources) and four as decoders (displays). Each device is connected to a network.

Configuration of each device, including which source is displayed on which display, can be achieved by any PC/laptop on the same network, using the VN-MATRIX Integrated Web Management System.



In this example each of the four sources is shown separately on the four displays. Potentially however, any display can display any source.

Data Transport Methods

Source data from a VN-MATRIX Encoder can be distributed to multiple displays/encoders (one-to-many) or to a single display/decoder (point-to-point).


Video data is transported from the source (encoder) to the display (decoder) using one of three methods:

- Multicast RTP
- Unicast RTP
- Unicast TCP

A description of each method, together with its advantages and disadvantages, can be found on the next few pages.

Multicast RTP

This method uses a real-time variation of UDP (User Datagram Protocol), called RTP (Real Time Protocol). Multicast RTP allows a source to be displayed on any number of displays.




The source encoder uses RTP to send data to a multicast group. The source does not need to know the IP address of any decoders that use that source.

RTP provides very low latency which is important for video transport. Unlike other protocols, RTP packets include a time-stamp. Therefore, if packets are received in the wrong order they can easily be sorted into the correct order for display, or discarded if the time stamp is 'out of date'.

However, because RTP is a connection-less protocol, data delivery is not guaranteed. Where data packets *are* lost (e.g. due to excessive network traffic) VN-MATRIX carefully manages the data stream to minimize any image disruption.

Unicast RTP

Like Multicast RTP this method uses a real-time variation of UDP protocol, called RTP. This method can be used where the network infrastructure does not support multicast traffic. Typically this should be used as a point-to-point configuration (*i.e.* single source to single display) but can be used for up to four displays.




The source encoder defines the display decoder(s) that the source is available to, but the decoder chooses which source to display.

RTP provides very low latency which is important for video transport. Unlike other protocols, RTP packets include a time-stamp. Therefore, if packets are received in the wrong order they can easily be sorted into the correct order for display, or discarded if the time stamp is 'out of date'.

However, because RTP is a connection-less protocol, data delivery is not guaranteed. Where data packets are lost (*e.g.* due to excessive network traffic) VN-MATRIX carefully manages the data stream to minimize any image disruption.

Unicast TCP

This method transports data using standard TCP (Transport Control Protocol) and should only ever be used for single point-to-point transfer of data.



TCP is a connection-based protocol and, therefore, data is *guaranteed* to be delivered. However, in the event of excessive network traffic, delivery may be delayed which will impact on real-time performance.

The decoder defines which source to 'connect to'. Other than defining an IP Address and source type (if required) no special source encoder setup required.

NOTE: *Multiple decoder connections are theoretically possible using this method but NOT recommended. Each additional connection will create extra loading on the encoder CPU which will ultimately result in poor display performance. In addition, multiple TCP streams carrying the same source data is an inefficient use of network bandwidth.*

Front Panel Features



Indicators

The following indicators are visible on the front of the VN-MATRIX:

Name	Color	Function												
POWER	Green	<i>Fully Lit</i> – when the unit is receiving power from the 12V supply input. <i>Flashing</i> – an over temperature condition has occurred or there was a power overload/underload condition. Cycle the power off/on to reset.												
NETWORK I	Orange	Indicates the status of network port I: <i>Fully Lit or Flashing Intermittently</i> – control or source data is being transmitted or received by the port. <i>Unlit</i> – no data or no network connection detected.												
NETWORK II	Orange	Indicates the status of network port II: <i>Fully Lit or Flashing Intermittently</i> – control or source data is being transmitted or received by the port. <i>Unlit</i> – no data or no network connection detected.												
STATUS	Green	Indicates the source status of the VN-MATRIX: <table border="1"> <thead> <tr> <th>Condition</th><th>Encoder (source)</th><th>Decoder (display)</th></tr> </thead> <tbody> <tr> <td><i>Unlit</i></td><td>No source input detected</td><td>No source being received</td></tr> <tr> <td><i>Flashing</i></td><td>Source being streamed</td><td>Source being received</td></tr> <tr> <td><i>Fully Lit</i></td><td>Source present but not being streamed (e.g. unit currently disabled or in standby mode)</td><td>n/a</td></tr> </tbody> </table>	Condition	Encoder (source)	Decoder (display)	<i>Unlit</i>	No source input detected	No source being received	<i>Flashing</i>	Source being streamed	Source being received	<i>Fully Lit</i>	Source present but not being streamed (e.g. unit currently disabled or in standby mode)	n/a
Condition	Encoder (source)	Decoder (display)												
<i>Unlit</i>	No source input detected	No source being received												
<i>Flashing</i>	Source being streamed	Source being received												
<i>Fully Lit</i>	Source present but not being streamed (e.g. unit currently disabled or in standby mode)	n/a												


NOTE: During the VN-MATRIX boot up period (typically 20-30 seconds) the NETWORK and STATUS indicators may light up or flash intermittently while the unit initializes.

Reset Button

VN-MATRIX is fitted with a concealed reset button. This can be used to reboot the operating system, for example during firmware upgrade procedures.

To activate this button, insert the blade of a very small screwdriver (or similar tool) or straightened paper clip into the hole on the front panel, on the left of the indicators.

Rear Panel Features



Full details of connector types, pin-outs and specifications can be found in Section 5: Technical Data. Briefly, these are as follows:

Power Supply Input

The VN-MATRIX requires a 12V DC regulated power supply (rated at 6A) via this connector. A suitable mains-operated power supply unit (PSU) is provided.

Network Connectors

These are used to connect the VN-MATRIX to an Ethernet network. Typically NETWORK I is used for data streaming and device configuration (using the Web Interface). NETWORK II port is reserved for future use and special applications.

Keyboard Connectors

Standard PS/2 connectors, used to connect the VN-MATRIX between the source computer and its keyboard.

Mouse Connectors

Standard PS/2 connectors, used to connect the VN-MATRIX between the source computer and its mouse.

Monitor Connectors

Standard DVI-I connectors, used to connect the VN-MATRIX between the source computer and its monitor. Compatible with both digital and analog sources – see Source Compatibility (page 11).

Serial I/O Connectors

Standard 9-pin connectors used to establish a serial data link between the VN-MATRIX and an external computer. COM1 is typically used to configure the unit via a serial link. COM2 is typically used for sending or receiving serial data across a network.

Accessories

Supplied Accessories

In addition to this User Guide, the VN-MATRIX is supplied with the following accessories. If any of these items is missing or damaged, please contact your Electrosonic dealer immediately:

Item	Qty	Re-order Code
12V Power Supply Unit (PSU)	1	ES3401-P
Mains Cord for PSU (with 3-pin 'Edison' plug) <i>For use in the USA.</i>	1	CA4291
Mains Cord for PSU (bare-ended) <i>For use in Europe and all other countries.</i>	1	CA429
Digital Monitor Cable (2 metre DVI-D to DVI-D)	1	<i>Digital Cable Kit:</i> ES3401-CD
Analog Monitor Cable (2 metre 15-pin HD-type to DVI-A)	1	
DVI-A to 15-pin HD Adapter	1	
Mouse/Keyboard Cable (2 metre PS/2 to PS/2)	2	<i>Analog Cable Kit:</i> ES3401-CA
Serial Cable (9-pin D-type to 9-pin D-type)	1	

Optional Accessories

The following optional accessories are also available for use with the VN-MATRIX – these must be ordered separately from your Electrosonic dealer:

Item	Order Code
Rack Mounting Kit (single unit) <i>A kit that allows a VN-MATRIX unit to be installed in a 19 inch equipment rack. Full instructions are included with the kit.</i>	ES3401-RM1
Rack Mounting Kit (dual unit) <i>A kit that allows two VN-MATRIX units to be installed, side by side, in a 19 inch equipment rack. Full instructions are included with the kit.</i>	ES3401-RM2
Surface Mounting Kit <i>A kit that allows a VN-MATRIX unit to be mounted to any convenient flat surface, e.g. under a desk. Full instructions are included with the kit.</i>	ES3401-SM

This page is intentionally left blank.

SECTION 2:

Installation & Basic Setup Procedures

Choosing a Suitable Location

The VN-MATRIX is designed to be used either as a free-standing unit or (by using the optional kits available) to be mounted in a 19 inch equipment rack.



CAUTION

Whichever installation method you choose there are certain environmental requirements, detailed on page 25, which must be observed in order to ensure safe and reliable operation.

For rack-mounted applications the criteria detailed on page 26, must also be observed.

Environmental Requirements



CAUTION

The criteria on this page must be observed for all installations of the VN-MATRIX, whether free-standing or rack-mounted.

Orientation

The VN-MATRIX is designed to be used free-standing on a stable, horizontal surface. It can, however, be used in any orientation subject to the necessary ventilation requirements.

Temperature

DO NOT install or operate the VN-MATRIX in an area where the ambient temperature exceeds 35°C (95°F) or falls below 5°C (35°F).

Remember that, as with all electronic equipment, the VN-MATRIX and its associated PSU also produces heat which may affect the ambient temperature.

After the VN-MATRIX has been in use for a period of time the external casing may become slightly warm to the touch. Ensure that any adjacent surfaces will not be affected by the heat.

Ventilation

DO NOT obstruct the ventilation grilles during use. The VN-MATRIX has an integral forced-air cooling system. A fan draws air in through the grille in the front panel and expels 'warmed' air through the grilles in the back panel. The fan speed is controlled automatically by an internal temperature sensor. The fan may, therefore, appear to run faster as the unit warms up or if the ambient temperature is increased.

A self-resetting thermal cut-out will shutdown the VN-MATRIX if the temperature exceeds design limits.

Humidity & Water

DO NOT install or operate the VN-MATRIX in an area in which the ambient relative humidity exceeds 85% or in an area that is prone to condensation.

DO NOT install or operate the VN-MATRIX near water or in a location which may be prone to water seepage — the VN-MATRIX is not waterproof.

Rack-mount Requirements



CAUTION

For rack-mounted installations, the following criteria must be observed (in addition to the Environmental Requirements listed on page 25)

Mounting & Support

ALWAYS use the special rack-mount kits (available separately) to secure the VN-MATRIX. Full details on using the kit are included with the kit. It will be necessary to remove the four feet prior to rack mounting.

DO NOT stand other units directly on top of the VN-MATRIX when it is rack-mounted as this will place excessive strain on the mounting brackets.

Ventilation

ALWAYS ensure that the rack enclosure is adequately ventilated. Sufficient airflow must be achieved (by convection or forced-air cooling) to satisfy the ventilation requirements of **all** items of equipment installed within the rack.

No additional ventilation gap is required above or below the VN-MATRIX and adjacent surfaces or equipment.

Mains Supply

ALWAYS ensure that the mains power supply is of the correct voltage and frequency for **all** equipment within the rack, and that it has a good ground/earth connection.

Where a power strip (mains distribution batten) is used (of either a hard-wired or plug and socket type), always ensure that the current rating of both the power strip and the supply is sufficient for all equipment within the rack.

Mains Power Connection (via PSU)

The VN-MATRIX must be powered from a 12 Volt DC regulated supply. A suitable mains-operated power supply unit (PSU) is provided. The mains connection details that follow relate to the PSU.



NEVER CONNECT THE VN-MATRIX DIRECTLY TO THE MAINS.

To ensure CE compliance **ALWAYS** use the PSU provided.
If a backup/replacement PSU is required, always use an Electrosonic approved PSU.

Supply Requirements (for PSU)



ALWAYS observe the following instructions to ensure safe and reliable operation of the PSU.

ALWAYS ensure that the mains supply voltage is single phase only and is within the permitted range:

- 100 – 240V AC (0.45A Max.) 50 – 60Hz.

NEVER connect the PSU to a DC supply.

DO NOT allow the mains power point to be overloaded. This is particularly important to check when powering several items of equipment from a single power point (e.g. within rack-mounted installations).

WARNING: THIS EQUIPMENT MUST BE GROUNDED / EARTHED.

WARNING: To avoid the possible risk of electric shock or product damage due to condensation, ALWAYS allow the PSU to become acclimatized to ambient temperature and humidity for at least thirty minutes BEFORE switching on. This is particularly important when moving the unit from a cold to a warm location.

Mains Power Cord (for PSU)

The mains PSU is equipped with a 3-pin (male) type mains connector which requires a power cord fitted with a corresponding 3-pin IEC320 (female) connector.

Two power cords are supplied with the PSU, each having a different termination; you must use the lead appropriate for your country:

In...	Use the...	Re-order Code
USA and Canada	cord fitted with the 3-pin American-style 'Edison' plug.	CA4291
UK, Europe and all other countries	unterminated cord and fit a suitable plug as described on page 29.	CA429

WARNING: Do not allow anything to rest on the mains power cord.

Power-up Procedure

You must always ensure that the VN-MATRIX is powered-up at the same time as the source computer or slightly before.

Powering the VN-MATRIX *after* the source computer may result in the source computer not correctly detecting the mouse, keyboard and/or monitor.

Fitting a Mains Plug

If you are fitting a plug to the unterminated power cord (or replacing an existing plug), you must fit a plug that:

- is rated for use with mains voltage
- is equipped with a grounding pin/connection
- complies with any applicable National or Local electrical regulations.
- is fitted with a correctly rated fuse (applicable to UK-style plugs only – see page 30.)

WARNING: Never attempt to fit or use a plug without a ground or earth pin/connection.

Wiring Details

The wires of both mains power cords (supplied with each VN-MATRIX) are color-coded as shown in the table below; be sure to connect your plug in accordance with the following guidelines:

Connect the wire colored...	to the plug terminal identified with...
Brown	'L' or 'Live' or 'Line' (or colored red or brown)
Blue	'N' or 'Neutral' (or colored blue or black)
Green & Yellow	'E' or 'E' or 'Earth' or 'Ground' (or colored green or green & yellow)
	WARNING — If you are unsure of the connections, or if the markings in your plug do not match those given above, CONSULT A QUALIFIED ELECTRICIAN.

NOTE: The PSU is double-insulated and does not require an earth/ground connection. However, the earth cable of the mains lead must be connected in the plug.

External Supply Protection



The mains power cord supplied with this product is rated at 10A maximum and must be protected from overload by an external fuse or circuit breaker.

Fused Plugs (UK-style)

If the power cord is fitted with a UK-style BS1363 3-pin plug (*i.e.* with provision for an internal fuse), then it must be fitted with a BS1362 ASTA approved 1 inch cartridge fuse.

This fuse must be rated at a **maximum of 10A/250V**. Since the current draw of the PSU is less than 1A, a fuse of a lower rating **not less than 3A/250V** may be used.

WARNING: Never attempt to fit a fuse or circuit breaker of a higher maximum rating than shown above.

Unfused Plugs or Hard-wired

If the power cord is fitted with an unfused plug, or is hard-wired into a power strip (mains distribution batten), then the power cord must be protected by an external fuse or circuit breaker of a rating shown in the table below:

Supply Voltage	110V nominal	230V nominal
Maximum Fuse Rating	10A	10A
Minimum Fuse Rating	3A	3A
WARNING: Never attempt to fit a fuse or circuit breaker of a higher maximum rating than shown above.		

Setup and Connection Procedure

Setting up and connecting a VN-MATRIX system is best undertaken in three stages. Briefly these are:


- **Stage 1: Network Communications Setup**
Configure the network settings for each device using a PC/laptop and serial data link, ensuring that one device is configured as a controller. (See pages 32 to 34).
- **Stage 2: Connection**
Connect each device to the network and connect its associated source or display equipment. (See pages 35 to 40).
- **Stage 3: System Configuration**
Using a PC/laptop connected to the same network to access the Web Interface (served by the controller) configure each device to be an encoder (source) or decoder (display). (See Section 3, page 41 onwards).

CAUTION: Do not proceed with connecting or configuring the VN-MATRIX for an existing network until you are certain you know what you are doing – incorrect connection or configuration may cause disruption to other network users.

Network Communications Setup

To establish a serial communications link...

- Using a null modem type serial cable, connect the serial port of a PC/laptop to the COM1 serial port on the VN-MATRIX to be configured:



- On the PC/laptop run a terminal emulation program such as HyperTerminal, with the following comms settings:

Baud rate: 115200
 Data bits: 8
 Parity: None
 Stop bits: 1
 Flow control: None

NOTE: *HyperTerminal is supplied with all Windows operating systems.*

To access the setup menus...

- Connect the power to the VN-MATRIX (or, if already connected, cycle the power off then on).
- VN-MATRIX will commence sending setup/diagnostic data which should appear in the HyperTerminal window. After a few seconds this will conclude with something like:

```
VN Matrix(R) Maintenance Console: ver3.1c

(none) login: ThorPci Init
registering plx interrupt routine = D17F89FC, -780166896
Hello kernel
thor_init_module: pre-ioremap
thor_init_module: post-ioremap
Hello kernel, this is MK registering
registering plx interrupt routine = D296BD30, 0
```

- Press the <enter> key: the VN-MATRIX should respond with the following login prompt:

```
VN Matrix(R) Maintenance Console: ver3.1c

192.168.0.1 login:
```

NOTE: The login prompt will be preceded by the current IP Address of the unit.

- Type **config** followed by the <enter> key.
- When prompted for a password type **config** followed by the <enter> key.

The following menu will then appear:

Network Port 1 =====	Network Port 2 =====
1. Boot method: static [dhcp]	11. Boot method: static [dhcp]
2. address: 192.168.0.18	12. address: 192.168.1.18
3. netmask: 255.255.255.0	13. netmask: 255.255.255.0
4. gateway: 192.168.0.1	
5. broadcast: 192.168.0.255	15. broadcast: 192.168.1.255
6. mtu: 1500	16. mtu: 1500
7. controller ip: 192.168.0.18	
8. controller port: 5432	18. webserver port: 80
9. Exit	

- Change the settings as required by typing the option number followed by the <enter> key. Then type the new value followed by the <enter> key.

For example, to change the Network Port 1 IP address to 172.28.232.16:

type **2** <enter> then type **172.28.232.16** <enter>

NOTE: Do not include any leading zeros when typing IP addresses.
For example, type 192.168.0.18 and not 192.168.000.018.

NOTES

- For advice on choosing IP Addresses, see Appendix A on page 126.
- For normal applications only Network Port 1 settings need to be configured.
- Option **1** and **11** are toggle action. For example, to switch between static and dhcp modes simply type **1** <enter>. The currently selected mode is the option listed first. When DHCP mode is selected, options 2, 3, 4 & 5 (or 12, 13 & 14) will not be displayed.
- Remember that one (and only one) VN-MATRIX must be configured as a controller (see below). The controller IP (option **8**) must be set to the IP Address of the unit designated as the controller.
- Gateway (option **4**) is generally only required if devices are on different subnets.

To configure VN-MATRIX as a controller...

- 🔧 Ensure the boot method for Network Port 1 is set to **static** (option **1**).
- 🔧 Set the IP Address (option **2**) and controller IP (option **8**) to the *same* value.

To implement the new settings...

- 🔧 Once you have made completed any changes, type **9** <enter> to exit the menu.

The VN-MATRIX will now reboot automatically to implement the new settings.

- 🔧 If the unit does not reboot for any reason, or you want to perform a manual reboot, type **reboot** <enter> at the command prompt (or cycle the power off and on) to reboot the unit and implement the new settings.

VN-MATRIX is now ready for connection to the network.

Connections

Supplied Cables

A set of cables is supplied with VN-MATRIX to accommodate a variety of standard connection requirements.

The VN-MATRIX is compatible with both digital (DVI) and analog graphics signals. The unit is provided with the necessary additional cables that you may require.

Cable Description	Source (encoder)		Display (decoder)	
	Digital	Analog	Digital	Analog
Mouse/Keyboard Cable (PS/2 to PS/2) (2 off)	✓	✓		
Digital Monitor Cable (DVI-D to DVI-D)	✓		✓	
Analog Monitor Cable (15-pin Hi-D D-type to DVI-A)		✓		✓
DVI-A to 15-pin Hi-Density D-type Adapter		✓		✓
<i>For Connection Diagram see page...</i>	37	38	39	40

IMPORTANT NOTES

Disconnecting and reconnecting PS/2 cables to a computer that is already switched on may cause loss of mouse/keyboard control or cause the computer to 'freeze'. It is recommended, therefore, that the connections are made while the computer is powered-down. See also 'Power-up Procedure' on page 28.

If you use a monitor cable or adapter other than that provided with the VN-MATRIX (as an encoder) you must ensure that all pins are properly interconnected, otherwise the computer graphics card or monitor may not operate correctly.

Network Connection


CAUTION: Do not proceed with connecting VN-MATRIX to an existing network until it is correctly configured using the procedure in Stage 1 (See pages 32 to 34). Incorrect connection or configuration may cause disruption to other network users.

Typically, the VN-MATRIX will connect to convenient network point on an existing in-house network. Use a standard CAT 5E or CAT 6 (or better) patch cable for this purpose. A patch cable is not supplied with the VN-MATRIX but is readily available in a variety of lengths from all good computer suppliers.


If a convenient network point is not available it will be necessary to have one installed – please consult the IT/Network Administrator or Building Facilities Manager for advice. Alternatively, the VN-MATRIX and source computer can ‘share’ a connection by using a switcher. Hubs are not suitable for use with VN-MATRIX as they restrict bandwidth.

For normal VN-MATRIX operation use Network Port I only.


HINT: *With the VN-MATRIX powered and connected to a network the Network Status Indicator (next to the network connector) should be lit:*




Connecting a Digital Source



Connecting an Analog Source




Connecting a Digital Display



NOTE: VN-MATRIX provides both an analog and digital output signal regardless of the original source format.

Connecting an Analog Display



NOTE: VN-MATRIX provides both an analog and digital output signal regardless of the original source format.

SECTION 3:

System Configuration

The VN-MATRIX Web Interface

Once all VN-MATRIX devices have been correctly set-up for (and connected to) a network, any system further configuration is achieved via the VN-MATRIX Web Interface. This comprises a number of 'pages' which provide access to various system parameters.

HINT: *This section provides step-by-step instructions for using the Web Interface and is aimed at new users of the VN-MATRIX system. Advanced users may wish to refer to the Quick Reference Guide in Section 7, pages 107 to 123.*

The Web interface is 'served up' by the VN-MATRIX device that was designated as the 'controller' during the network set-up procedure (see page 34). It can be viewed by any up-to-date web browser, running on a PC/laptop that is connected to the same network as the VN-MATRIX devices.

Suitable browsers include (but are not necessarily limited to):

- Internet Explorer (v6 and above),
- Firefox/Mozilla (v1.3 and above).
- Netscape (v6 and above), and

IMPORTANT: *Whatever browser is used, it must be configured to accept cookies and be JavaScript-enabled. For further help on configuring your browser, refer to Appendix C (page 133 onwards).*

Accessing the Web Interface

Use the address box of your chosen browser to enter the following URL:

http://xxx.xxx.xxx.xxx

where xxx.xxx.xxx.xxx is the IP address of the VN-MATRIX controller.

The following page will appear in the browser:



Click the text as directed to reveal the login screen:

A login page with a light orange background. At the top, there is a black header bar containing the 'vnmatrix' logo. Below the header, the text 'VN-Matrix Integrated Web Management System' is centered in a bold, black font. Underneath that, 'Login Page' is also centered in a bold, black font. Further down, there are two input fields: 'User name:' followed by a white text box, and 'Password:' followed by a white text box. Below the password field is a small blue button with the word 'Login' in white text.

Enter the appropriate **User name** and **Password**.

VN-MATRIX has two user accounts:


- **admin** – which allows full *read/write* access to all setup parameters,
- **public** – which allows *read only* access to setup parameters.

Initially the password for both accounts is the same as the user name (*i.e.* the account name). It is recommended that these are changed once commissioning is complete (see page 81).

Click the **Login** button.

If the login details are correct the **Device List** page will appear (see next page).

The Device List Page



This page lists all VN-MATRIX devices detected on the network.

NOTE: *If devices are added after this page is displayed they will not automatically appear on this list. You will need to refresh the list by clicking the **Device List** tab, or by clicking the browser Refresh/Reload button.*

Once a VN-MATRIX device has been detected and been listed on the Device List page, an entry will be displayed even if the device is subsequently disconnected. All valid devices are listed by device name and followed by their current IP address. 'Missing' devices are easily identified by the lack of an IP Address. In the above example, the last device in the list (device 620098) is not currently available (e.g. may be disconnected from the network or powered-down).

The current configuration status of each device is also identified by an icon:

-  unconfigured
-  configured as an encoder (source)
-  configured as a decoder (display)

In a new system, all VN-MATRIX devices will typically be in an unconfigured state. The remainder of this section will guide you through the process of configuring each VN-MATRIX as either an encoder (source) or decoder (display).

On-line Help

On-line help is available for each page in the Web Interface by simply clicking the  tab.

Interface Timeout & Logging Out

If the web interface is left unattended or is not used for a period of 30 minutes it will automatically logout. You can start using the interface again by re-entering your login details.

To logout of the Web Interface...

 Click the  tab on any page.


Update Button and Save Tab

Most pages in the web interface have an **Update** button and/or a **Save** tab:

	Clicking the Update button implements the settings for the current page/device but does not save them to the VN-MATRIX flash memory, <i>i.e.</i> if the unit is rebooted the previous settings will be used.
---	--

	Clicking the Save tab implements the settings for the current page/device and does save them to the VN-MATRIX flash memory.
--	---

On the **Device List** page only there is a **SaveAll** tab:

	Clicking the SaveAll tab will save all current settings (including those that have been 'updated') for all VN-MATRIX units.
---	--

Configuring a VN-MATRIX as an Encoder (source)

The following procedure assumes that a valid source is connected to the VN-MATRIX.
For details on how to connect a source, see page 37 and 38.

NOTE: This procedure provides a basic level of configuration which will be adequate for most systems. For additional 'Advanced Setup' options, see pages 62 to 74.

The image shows two screenshots of the VN-MATRIX web interface. The top screenshot shows the 'Device List' page with a list of devices. A callout box points to the first device, 'device620030/192.168.0.4', with the text: '1 On the **Device List** page click the device that you want to configure. The **Device** page will then appear...'. The bottom screenshot shows the 'Device' configuration page for 'device620039'. A callout box points to the 'create source' button with the text: '2 Click the **create source** button. Turn to page 47.' Another callout box points to the 'Name' field with the text: 'HINT: You can change the default device **Name** to be more relevant to the source input (e.g. Camera1). NOTE: Device names can use letters and numbers, as well as the underscore and hyphen characters, but must not include spaces.'

Device List Accounts SaveAll Help Logout

VN-Matrix Controller

device620030/192.168.0.4
device620091/192.168.0.3
device620095/192.168.0.1
device620096/192.168.0.6
device620097/192.168.0.2
device620098/192.168.0.5

1 On the **Device List** page click the device that you want to configure.
The **Device** page will then appear...

Device List Device Upgrade Serial Save Help Logout

Device [device620039]

Name device620095
Serial Number 620039
Status Active LinkStatus: Good
IP address:port(cport) 172.28.230.140:9001(5432)

Type
Device Type none create source create display
Mode enable

License
Structure V1,A1,D1,mA,mH,oS,oD,Z

2 Click the **create source** button.
Turn to page 47.

HINT: You can change the default device **Name** to be more relevant to the source input (e.g. Camera1).
NOTE: Device names can use letters and numbers, as well as the underscore and hyphen characters, but must not include spaces.

3 Check that the **Mode** field is set to **enable**.
For more information, see 'Device Mode' on page 49.

4 Click the **Save** tab.

5 Click the **videoPort0** icon.
The **Configure** page will appear...

HINT: To help identify this device during set-up or troubleshooting, tick the **Identify** box to display the device name on the local monitor (where connected).
For more information, see 'Identify Mode' on page 49.

6 Check that the **Input Mode** is set to **auto**.
If not, see 'Input Mode' on page 49.

7 Check that the **Current Mode** shows the format of the connected source.
If not, see 'Input Mode' on page 49.

8 Tick the **Multicast Enable** box if RTP Multicast source streaming is required, otherwise ensure this box is unticked to enable RTP Unicast.

HINT: If your source or local monitor uses EDID, you may need to look at these settings.
For more information, see 'EDID Options' on page 49.

9 Does the source have an audio channel?

NO...

Encoder setup is complete, click the **Save** tab.

If a local monitor is connected it should now be displaying the source.
If not, see 'Source Checkup on page 1058.

YES...

Turn to page 48 and follow 'Additional Setup for Audio'

- 10** Repeat this procedure (from page 46, step **1**) for each encoder in the system.
To configure a VN-MATRIX device as a decoder (display), turn to page 51.

Additional Setup for Audio

1 Click the **Device** tab to return to the **Device** page...

2 Click the **audioPort0** icon.
The **Configure** page will appear...

3 Check that the **Audio Status** shows a valid audio source type. If not, see page 50.

4 Ensure that **Compression** is set to **no compression**.
For further information on this feature, see page 73.

- 5 Tick the **Multicast Enable** box if RTP Multicast source streaming is required, otherwise ensure this box is unticked to enable RTP Unicast. This must be the same as the **videoPort** setting.

- 6 Encoder setup is now complete, click the **Save** tab.

Repeat this procedure (from page 46, step 1) for each encoder in the system.
To configure a VN-MATRIX device as a decoder (display), turn to page 51.

Input Mode

The default and recommended input mode for a VN-MATRIX encoder is **auto**. This mode provides full detection of the applied source and automatic configuration of input parameters. It has the additional advantage that if a different source is connected at any time, the VN-MATRIX will automatically re-configure the input for the new source.

Auto mode will detect most standard video and graphic source formats. However, if the source input:

- is a non-standard format,
- is an RGsB (sync on green) or YPrPb source type,
- has a poor quality signal,
- has Macrovision® copy protection

then VN-MATRIX may not auto-detect correctly. In these cases, to achieve reliable operation, some fine-tuning may be necessary. A pre-defined or custom input mode can also be applied.

For further information, see 'Advanced Source Setup' on page 63.

EDID Options

Many modern computers and monitors are capable of using EDID (Extended Display Identification Data). This allows a computer graphics card to be 'aware' of the capabilities of the display connected to it. VN-MATRIX, when configured as an encoder, provides different options for handling EDID.

Monitor Edid	No Device	The Monitor EDID field shows the local monitor display type. If no local monitor is connected or the monitor does not support EDID, this will show No Device.
Reported Edid	transparent	


Identify Mode

As an aid to setting-up a VN-MATRIX encoder in a large or complex system, use the **Identify** function to display the device name on the local monitor (if fitted).

Tick the **Identify** checkbox, then click the **update** button. The device name will appear on the local display (see example right).

NOTES

- The name will only display if a valid source is connected and has been correctly detected by VN-MATRIX.
- The name only displays on the local display output. It does not appear as part of the streamed source.



Device Mode

A VN-MATRIX encoder can be configured in three modes:

- **enable** allows the source to be streamed,
- **disable** prevents a source from being streamed,
- **standby** prevents a source from being streamed.

For normal operation, **enable** must be selected.

Audio Status

Where a valid digital audio signal is connected to the **DIGITAL AUDIO IN** connector, the type of signal will appear in the **Audio Status** field on the **Configure (audioPort)** page.

VN-MATRIX supports the auto-detection of **44100 Hz** and **48000 Hz** digital audio sources.

Advanced Setup Options

The encoder set up procedure on the preceding pages will achieve a basic level of operation which will be adequate for most normal applications.

The following advanced setup options are possible and these are detailed in Section 4:

Fine-tuning of input parameters	see page 65
Creation of custom input modes	see page 66
Changing video compression	see page 69
Managing bandwidth usage	see page 72
Changing audio compression	see page 73

Configuring a VN-MATRIX as a Decoder (display)

The following procedure assumes that at least one VN-MATRIX encoder has been configured and is ready to stream a source (see page 46)

It is also assumed that a suitable display device is connected to the VN-MATRIX.
For details on how to connect a display, see pages 39 and 40.

NOTE: This procedure provides a basic level of configuration which will be adequate for most systems. For additional 'Advanced Setup' options, see pages 74 to 81.

The image shows two screenshots of the VN-Matrix Controller web interface. The top screenshot shows the 'Device List' page with a list of devices. A callout box points to the list with the text: '1 On the **Device List** page click the device that you want to configure. The **Device** page will then appear...'. The bottom screenshot shows the 'Device' configuration page for device 'device620097'. A callout box points to the 'create display' button with the text: '2 Click the **create display** button. Turn to page 52.'.

Device List Page:

- vnmatrix
- Device List | Accounts | SaveAll | Help | Logout
- VN-Matrix Controller
- device620030/192.168.0.4
- device620091/192.168.0.3
- device620095/192.168.0.1
- device620096/192.168.0.6
- device620097/192.168.0.2
- device620098/192.168.0.5

Device Configuration Page:

- vnmatrix
- Device List | Device | Upgrade | Serial | Save | Help | Logout
- Device [device620097]
- Name: device620097
- Serial Number: 620039
- Status: Active
- IP address:port(cport): 172.28.230.140:9001(5432)
- LinkStatus: Good
- Type: Device Type: none
- Mode: enable
- License: Structure: V1,A1,D1,mA,mH,oS,oD,Z
- Buttons: create source, create display

HINT: You can change the default device **Name** to be more relevant to the source input (e.g. Screen1).

NOTE: Device names can use letters and numbers, as well as the underscore and hyphen characters, but must not include spaces.

4 Click the **Save** tab.

3 Check that the **Mode** field is set to **enable**.
For more information, see 'Device Mode' on page 54.

5 Click the **display0** icon.
The **Display** page will appear...

HINT: To help identify this device during set-up or troubleshooting, tick the **Identify** box to display the device name on the local monitor (where connected).
For more information, see 'Identify Mode' on page 54.

6 Check that the **Output Format** is set to **auto**.
This forces the output format to be the same as the chosen source.

6 If the source type is **RGsB** (sync on green), ensure that **SoG** is ticked. Otherwise it should be left unticked.
This forces the output format to be the same as the chosen source.

HINT: The **Nodata Splash** option determines how the display output behaves if no source is selected or if the source stops streaming for some reason.
For more information, see 'Nodata Splash Mode' on page 49.

The screenshot shows the vnmatrix web interface. At the top, there's a header with the 'vnmatrix' logo and buttons for 'Save', 'Help', and 'Logout'. Below the header, there's a sidebar with a 'Dev' icon and a list of devices. The main content area has a form for selecting a source. A callout box labeled '7' explains that sources are listed by device name, videoPort name, and connection type, and provides examples: '_rtp' for RTP Unicast, '_rtp(m)' for RTP Multicast, and '_tcp' for TCP Unicast. The form has tabs for 'bandwidth', 'source', and 'audio'. The 'source' tab is active, showing a dropdown menu with options like 'Please select a source', 'Import Source', and several device-specific options. A callout box labeled '8' points to the 'audio enable' checkbox, stating that it should be ticked if the chosen source has an audio channel. An 'Update' button is at the bottom left of the form.

7 Select one of the available **source** streams.

Each source is listed by the device name, videoPort name and suffixed by the connection type:

- _rtp** is an RTP Unicast connection,
- _rtp(m)** is an RTP Multicast connection,
- _tcp** is a TCP Unicast connection.

8 If the chosen source has an audio channel, tick the **audio enable** box. Otherwise leave this box unticked.

9 Click **Update** and **Save**.

The chosen source should now appear on the output display.
If not, please refer to 'Display Checkup' on page 57.

Additional Information for Decoder Setup


Identify Mode

As an aid to setting-up a VN-MATRIX decoder in a large or complex system, use the **Identify** function to display the device name on the display output.

Tick the **Identify** checkbox, then click the **update** button. The device name will appear on the display (see example right).

NOTES

- The name will only display if a valid source is currently selected and being displayed.
- The name only displays on the selected output device only. It does not appear as part of the streamed source on other displays.



No Data Splash Mode

If a VN-MATRIX decoder cannot display a source (e.g. if no source is selected, has become disconnected or is in the wrong format), it offers two different display options.

The required option is selected using the **Nodata Splash** checkbox:

- **Nodata Splash** ☒ Display a splash screen (see example right), or
- **Nodata Splash** ☐ Display the last frame of valid source data (black if no data is available).



Device Mode

A VN-MATRIX decoder can be configured in three modes:

- **enable** allows the selected source to be displayed,
- **disable** prevents a source from being displayed (display is blank),
- **standby** prevents a source from being displayed (display shows 'no data' splash screen).

For normal operation, **enable** must be selected.

Advanced Setup Options

The decoder set up procedure on the preceding pages will achieve a basic level of operation which will be adequate for most normal applications.

The following advanced setup options are possible and these are detailed in Section 4:

Setting optimum playback delay	see page 75
Monitoring bandwidth usage	see page 76
Creation of custom output modes	see page 78


Troubleshooting

If you have followed the procedures on the preceding pages, you should by now have at least one VN-MATRIX encoder and one VN-MATRIX decoder and be able to display the source (encoder) on the display (decoder). If not, this section will help to diagnose most problems that you may encounter.

Most problems in a VN-MATRIX system will manifest themselves as some kind of disruption of the target display. Use the Display checkup (see page 57) as a starting point to trace common problems, either with the decoder/display or elsewhere in the system.


Display Checkup

Most problems in a VN-MATRIX system will manifest themselves as some kind of disruption of the target display. Use this checkup as a starting point to trace common problems, either with the decoder/display or elsewhere in the system.




Source Checkup

When attempting to diagnosing problems with an encoder or source it is highly recommended that a local monitor is connected to the VN-MATRIX. If a monitor is not already connected as part of the system, it is suggested that one be connected temporarily.




System Checkup

Follow this checkup to ensure that all VN-MATRIX devices in your system are online and correctly configured as either Encoders or Decoders.



Controller Checkup

Follow this checkup if you cannot establish contact with the VN-MATRIX controller device using the Web Browser on you control PC.



SECTION 4:

Advanced Setup Procedures

Encoder Set Up

This section provides details for advanced set up options for a VN-MATRIX encoder.

Fine-tuning of input parameters	see page 65
Creation of custom input modes	see page 66
Changing video compression	see page 69
Managing bandwidth usage	see page 72
Changing audio compression	see page 73

Advanced Source Setup

For most applications it is recommended that the source input of VN-MATRIX is set to **auto** mode. This enables the device to detect the electrical/timing characteristics of the input signal and determine the exact source type. It will then invoke the appropriate input parameters for optimum processing of that source.

This also has the advantage that if the input source changes to another source type (*e.g.* if the source input is derived from a source switcher) it can change input setup 'on the fly' without any user intervention.

While the **auto** mode will work with most standard video/graphics standards, there are some circumstances, particularly with analog sources, where some additional fine-tuning may be required. For example, when the source:

- is an RGsB (sync on green) or YPrPb source type,
- has Macrovision[®] copy protection,
- does not have a completely standard signal format,

In extreme circumstances, it may even be necessary to create a custom input mode. For example, when a source:

- is completely non-standard,
- has a poor quality signal.

Video Setup Page

All advanced source setup is achieved via the **Video Setup** page. This is accessed by clicking the **Video Setup** tab on the **Configure** (videoPort) page for the relevant VN-MATRIX encoder:

The screenshots illustrate the navigation path to the Video Setup page:

- Home Page:** Shows the VN-Matrix Controller interface with a list of devices.
- Device Configuration:** Clicking on a device (e.g., device620095) leads to its configuration page.
- Configure Page:** From the Device configuration page, clicking the 'Configure' tab leads to the 'VideoPort' configuration page.
- Video Setup Page:** From the 'VideoPort' configuration page, clicking the 'Video Setup' tab leads to the 'Video Setup' page.

Video Setup Page Details:

- name:** videoPort0
- mode:** 1280x720p_60Hz_SMPTE
- phase:** auto
- macrovision defeat:** ☐
- colour space:** RGB
- blanking:** auto
- pixels:** 0
- lines:** 0
- Buttons:** Resync, Update, Save Source
- Options:** Interlace, Fixed Geometry, Trisync Ignore

Callout Box:

For most source types it is recommended that you select the **auto** input mode, allowing full auto-detection of the source.

To apply a fixed input mode, select the required mode from the drop down list and click **Update** or **Save**.

NOTE: Selecting a fixed input mode disables the auto-detect function.

Fine-Tuning a Source (manual overrides)

The following adjustments are classed as manual overrides. The chosen settings are not saved as part of the current source **mode** and, once applied, will remain in force until they are changed.

Phase (Pixel Clock)

When an analog graphics signal is being digitized it is essential that each pixel is sampled as close as possible to its center in order to obtain a stable value. Sampling too close to a pixel boundary will cause unreliable data capture and result in noise or artifacts, especially between pixels of significantly different hue or intensity.

Normally **phase** is set to **auto**. This allows VN-MATRIX to automatically determine the optimum clock phase. If the auto setting proves unsatisfactory for any reason, try adjusting the **phase** manually by selecting a value between **+32** and **-32**. Positive numbers advance the clock phase relative to the start of the active line while negative numbers retard the clock phase.

HINT: Optimum phase adjustment is easier to establish when a suitable test pattern is displayed. Typically, this will comprise a series of alternating black and white vertical lines at one pixel intervals.

Macrovision Defeat

Macrovision copy protection is often applied to commercially produced videos and DVDs. This adds additional sync-level pulses to the video waveform and these need to be ignored for proper auto-detection on VN-MATRIX.

If you know (or suspect) that your source material has Macrovision encoding, tick the **Macrovision defeat** option on the **Video Setup** page.

Leave this parameter unticked for all other sources. Ticking this parameter for non-Macrovision sources may result in 'tearing' at the top of the image.

The screenshot shows the 'Video Setup' page for a device named 'device620095'. The interface includes a top navigation bar with 'Setup', 'Help', and 'Logout' links. The main content area has a left sidebar with a tree view showing 'Device Setup' and 'Source Setup'. The main panel contains the following settings:

- name:** videoPort0
- mode:** 1280x720p_60Hz_SMPTE (dropdown)
- phase:** auto (dropdown)
- macrovision defeat:** ☐ (checkbox)
- colour space:** RGB (dropdown)
- blanking:** auto (dropdown)
- pixels:** 0 (text input)
- lines:** 0 (text input)

Buttons for 'Resync', 'Update', 'New Source', and 'Save Source' are present. Below the settings, a table shows source status information:

Source status	LineCount	LinePeriod(ns)
stream status		
lockStatus		
monLineCount		
monLinePeriod		
digHSize		
digVSize		
digFirstPixel		
digFirstLine		
phase		

Four callout boxes provide detailed information about the settings:

- Phase (Pixel Clock):** Explains the importance of sampling pixels correctly and provides a hint for manual adjustment using test patterns.
- Macrovision Defeat:** Explains that this option is used to ignore Macrovision copy protection pulses.
- Blanking (Image Positioning):** Explains that this parameter controls the position of the first active line and pixel, used for horizontal and vertical blanking signals.
- Color Space (RGB / YPrPb):** Explains that the wrong color space can cause a color cast and provides instructions to set it to RGB or YPrPb.

Creating a Custom Input Mode

A custom input mode allows you to specify your own values for the various input parameters, e.g. number of lines/pixels of active video, the start line/pixel of active video, etc.

When VN-MATRIX performs an auto-detect on a non-standard source, it will usually be able to choose an existing mode that 'best matches' the source. This will then provide the starting point for you to make adjustments and create your custom mode.

However, if VN-MATRIX cannot find a suitable mode, you will need to obtain technical data about the source to be able to enter the required input parameters.

Custom input modes are created using the Video Setup page (see page 64).

HINT: The Device Status attributes are the set of measurements used by the auto-detection mechanism when searching for the closest Source Format match. If a non-standard source type is being used a user derived Source Format can be constructed on this screen by considering the current Device Status values.

name: mode: phase: macrovision defeat: ☐ colour space:

blanking: pixels: lines:


Device Status currentMode : XGA 60Hz type : analog hv progressive source status : active stream status : (1,1) lockStatus : 1 monLineCount : 806 monLinePeriod(ns) : 20652 digHSize : 1022 digVSize : 766 digFirstPixel : 302 digFirstLine : 37 phase : 3	User Source Format New Source Save Source Name: LineCount: Interlace: ☐ LinePeriod(ns): Fixed Geometry: ☐ PixelsPerLine: Trisync Ignore: HSize: VSize: FirstPixel: FirstLine:
--	---

To create a Custom Source Mode...

- 1** Using the **Name** listbox, select a source type similar to the input source.

This will act as a template on which your custom mode will be based.

- 2** Click the **New Source** button and enter a new name for the new source type in the popup box:



- 4** Copy the **monLineCount** value (in the Device Status section) to the **LineCount** field.

Copy the **monLinePeriod** value (in the Device Status section) to the **LinePeriod** field.

- 3** If it is an interlaced source, tick the **Interlace** box. For progressive sources ensure that this box is unticked.

- 5** Select the new source name in the **mode** pull down. This forces auto-detection to always choose the new mode.

Click **Resync** to force the auto-detection algorithm to select your new mode.

- 6** If necessary, modify the **HSize** and **VSize** fields to be the same as the **digHSize** and **digVSize** measurements. These will only reflect the true source values if the screen is showing content across its full extent.

If necessary, modify the **FirstPixel** and **FirstLine** fields to be the same as the **digFirstPixel** and **digFirstLine** measurements.

- 7** Iteratively modify the **PixelsPerLine** value and click the **Resync** button.

When the value is correct sampling across a line will not show any aliasing. This is best done using a moire test pattern or with a screen of fine text.

- 8 Set **blanking** mode to **manual** and check that the **pixels** and **lines** values are both set to zero. Then...

name videoPort0
mode Custom XGA Source phase auto macrovision defeat ☐ colour space RGB
Resync Update blanking manual pixels 0 lines 0

... iteratively modify the **FirstPixel** and **FirstLine** values to correctly show the full extent of the screen.
After each change click **Resync** to force a re-detection.

monLineCount : 800
monLinePeriod(ns) : 20652
digHSize : 1022
digVSize : 766
digFirstPixel : 302
digFirstLine : 37
phase : 3

format New Source Save Source
Custom XGA Source
806 Interface ☐
20677 Fixed Geometry ☐
1344 Trisync Ignore 0
1024
768
296
35

- 9 Set **blanking** mode back to **auto**. Then...

name videoPort0
mode auto phase auto macrovision defeat ☐ colour space RGB
Resync Update blanking manual pixels 0 lines 0

... set the source **mode** back to **auto** and click the **Resync** button.
Verify that the new mode is correctly selected.

monLineCount : 800
monLinePeriod(ns) : 20652
digHSize : 1022
digVSize : 766
digFirstPixel : 302
digFirstLine : 37
phase : 3

format New Source Save Source
Custom XGA Source
806 Interface ☐
20677 Fixed Geometry ☐
1344 Trisync Ignore 0
1024
768

- 10 Click the **Save Source** button to save the new source format in non-volatile storage.

NOTE: Once saved a custom source format is stored on the VN-MATRIX controller device and becomes available to all VN-MATRIX encoder devices.

Managing Compression & Bandwidth Settings

VN-MATRIX can apply various types of compression to an input source in order to reduce the volume of source data being streamed across the network.

In addition, various parameters are provided to manage and, if necessary, limit the amount of data flow to ensure that the available network bandwidth is not exceeded.

The default compression settings applied by VN-MATRIX offer a good balance between the quality of the displayed material and network bandwidth. Where network bandwidth is restricted, extra compression can be applied. Depending on the source type and content, significant reduction in streamed data can be achieved with little or no perceptible affect on image quality.

Alternatively, where network bandwidth is not an issue, compression can be removed altogether. However, in most cases, there is no real benefit in doing this due to the highly efficient compression algorithms used by VN-MATRIX.

All compression and bandwidth settings are accessed via the Bandwidth Page (see page 70).

Bandwidth (source) Page

All advanced source setup is achieved via the **Bandwidth** (source) page. This is accessed by clicking the **Bandwidth Management** button on the **Configure** (videoPort) page for the relevant VN-MATRIX encoder:

The diagram illustrates the navigation path to the **Bandwidth Management** page for a specific video port. The path starts from the **Device List** page, moves to the **Device** configuration page for a specific device, then to the **VideoPort** configuration page for a specific video port, and finally to the **Bandwidth Management** page.

Bandwidth Management

Compression

Luminance: 5 Lock: ☒

Chrominance: 7

Quality Control: Advanced

Temporal: ☒

Threshold: 0 Chroma: ☐

Refresh Rate: 1

Transform: graphics

Motion: 0

update

Bandwidth

Mode: none

Target Bandwidth (Mbps): 0.000

Frame Drop Percentage: 0

Streams

Connection	Destination	Transport	Scope	IP address	Delete

Compression Settings

The Luminance and Chrominance settings can be individually modified (**Lock** unchecked) or they can be locked together (**Lock** checked).

When locked together the Chrominance tracks the Luminance setting plus 2 stops.

The **Luminance** compression can be modified between 0 and 10, where 0 is no compression and 10 is maximum compression. The picture may look noticeably 'blocky' at higher compression values. A value of **4** is a good compromise for efficiency and visual integrity.

The **Chrominance** compression can be modified between 0 and 11, where 0 is no compression and 11 is maximum compression. Excess screen artifacts will become visible if the chrominance compression is set more than two points above the luminance setting. A value of **6** is a good compromise for efficiency and visual integrity.

Quality Control Settings

These settings control the dynamic nature of the compression system - how the system responds to changes in the source input.

Choose the preset option that best matches the type of imagery and the type of compression to be applied or choose **Advanced** and adjust the settings as follows:

Temporal compression causes areas of the screen to be refreshed only when a change between frames is detected. Enabling temporal compression can significantly reduce network bandwidth. It is best used with the screen refresh capability. For all normal operation it is suggested that temporal compression is enabled.

Threshold controls the sensitivity of the temporal change detection algorithm. A value of 0 means any screen changes will be sent. Increasing the value increases the send threshold and reduces the network bandwidth. A setting of 0 is suitable for DVI computer generated sources. Sources with more noise or video-type motion should use a setting between 1 and 4. Camera sources should always use value greater than 0.

Chroma controls whether the temporal algorithm should consider changes in the color or chrominance of the image. Enabling Chroma gives better results on digital simulation type sources, however Chroma thresholding can increase the transmit bandwidth by up to 200% so it should be disabled on bandwidth sensitive systems. It is usually not required on video/camera type sources.

Refresh Rate controls how frequently the non-changing parts of the screen are updated in temporal compression mode. This is useful when connecting new displays to a temporally encoded source and to fill in gaps in the data when using a lossy network transport such as RTP. A value of 1 refreshes the screen in one second, a value of 0.1 refreshes the screen 10 times per second. A value of 0 disables the refresh.

The compression system supports two **Transform** types:

- **Graphics** is optimised for text and sharp lines, such as is present on most computer screens.
- **Video** is optimised for smooth tone changes such as is present in movies and other video content.

Motion compression can be modified between 0 and 15, where 0 is no additional motion compression and 15 is full motion compression. When enabled, where motion is detected on the screen that area is compressed more heavily. This reduces bandwidth at a time when the eye cannot perceive significant detail. When the motion stops the screen area is resent at the standard resolution preserving the screen integrity.

Bandwidth Management Settings

Bandwidth

Mode: none

Target Bandwidth: 0.000

Frame Drop Percentage: 0

Streams

#	Destination	Trans	BW(Mbps)	Drop%	RTT(us)
1	device620165.videowindow	rtp	32.228	0.0	427

VN-MATRIX can apply various bandwidth management policies and these can be selected using the **Mode** parameter:

- **None** – no bandwidth management policy will be followed apart from the underlying compression settings.
- **Manual Frame Drop** – allows the user to specify the precise fraction of frames to drop. This doesn't manage the bandwidth at a fixed level, but does result in a smoother update given rapidly changing video content types. The percentage of frames to discard is entered into the **Frame Drop Percentage** field. For example, a value of 95 (i.e. 95%) will discard 19 out of every 20 frames and will therefore reduce a 60 fps video signal to 3 fps.

NOTE: *Slowing the frame rate to around 1fps may cause the decoder to behave as if the source stream has been interrupted and it will start flashing up the 'no source' splash screen.*

- **Shared Flowrate** - the total network video traffic for all streams of this source is limited to the flowrate (in kbps) specified in the **Target Bandwidth** field. Frames are dropped if the instantaneous data rate is higher than the flowrate.
- **Peak Flowrate** - the network video-traffic for each stream of this source is limited to the flowrate (in kbps) specified in the **Target Bandwidth** field.. Frames are dropped if the instantaneous data rate is higher than the flowrate.

Flowrate control modes limit the instantaneous traffic on the network and are useful where the network pipe between source and display has limited bandwidth and drops traffic when this rate is exceeded. Non-flowrate control modes limit the average bandwidth but the instantaneous bandwidth can be high. Non-flowrate control modes are best used on a LAN where the user does not wish VN-MATRIX to consume excess bandwidth.

IMPORTANT NOTE: *The bandwidth management is applied to each source data stream separately. Thus actual bandwidth usage will be multiplied by the number of source data streams. For example, if the encoder has two Unicast RTP connections plus a TCP connection, it will actually be sending three data streams across the network.*

The **Streams** list shows network statistics for current RTP streams. For each RTP stream three values are presented: the Transmit Bandwidth (in Megabits-per-second), the packet Drop Percentage and the Round Trip delay Time (in microseconds). The Bandwidth is the true bandwidth of the source measured over the last second. All of this data may not have arrived at the destination if the link shows packets are being dropped. Most networks show a small amount of dropped traffic but when this rises above 5% it indicates the capacity of the link has probably been exceeded. A lightly loaded network will show a fairly constant RTT. When this value starts to rise or fluctuates excessively it indicates the network is congested. Usually when network capacity has just been exceeded the RTT will rise to a large value just before packets start being dropped. The link latency will rise as RTT increases.

The **Streams** box can be hidden/revealed by clicking on the arrow in the tab. When the box is hidden the auto-updating function is suppressed which reduces system load.

Audio Compression

The S/PDIF digital data bus can carry two types of data:

- 2 channel (stereo) uncompressed audio, or
- encoded digital data, typically AC-3 (Dolby Digital) format.

VN-MATRIX supports limited compression of S/PDIF audio sources. This is controlled by the **Compression** setting on the **Configure (audioPort)** page. The following compression options are available:

Compression	2 channel audio source	AC-3 audio source
no compression	24 bit native data (2975 kbps)	24 bit native data (2975 kbps)
compress 1	16 bit data, full sample rate (1517 kbps)	16 bit data, zeros run length encoded (430 kbps)
compress 2	16 bit data, 1/2 sample rate (784 kbps)	16 bit data, zeros run length encoded (430 kbps)
compress 4	16 bit data, 1/4 sample rate (418 kbps)	16 bit data, zeros run length encoded (430 kbps)

NOTE: *The native uncompressed setting passes the full 24 bit payload plus the 4 S/PDIF control bits updating on a continuous frame basis. Other modes only transmit 16 bit data and reduce the S/PDIF control bits update rate to once per second.*

Decoder Set Up

This section provides details for advanced set up options for a VN-MATRIX decoder.

Setting optimum playback delay	see page 75
Monitoring bandwidth usage	see page 76
Creation of custom output modes	see page 78

Setting Optimum Playback Delay

During playback of a source stream, data is transported from a VN-MATRIX encoder across the network and into a buffer on the VN-MATRIX decoder. Data is then read from the buffer and output to the display. Because of the inherent time delay (latency) for data to be transported across the network, it is clearly not possible for the decoder to display the source at exactly the same instant as it is being encoded.

For this reason the VN-MATRIX decoder imposes a Playback Delay to take account of the total data transit time. It also ensures smooth playback of a source stream by equalizing the flow of data into and out of the decoder buffer.

Setting the Playback Delay too small may cause the buffer to 'underrun' (data is read from the buffer quicker than it can be written). This will result in the playback image jumping as network loading changes.

Setting the Playback Delay too large will cause excessive image latency and may, particularly on high bandwidth datastreams, cause the buffer to 'overflow' (data is written to the buffer quicker than it can be read). This will result in 'jumpy' screen updates and screen flashing.

NOTE: *When a source has both a video and audio stream, these are treated separately and can be subject to different processing delays. In many applications this will not present any noticeable issues. However, with some source material, especially where correct 'lip-sync' must be maintained, it may be necessary to set different values for the video and audio Playback Delay.*

The default Playback Delay is 0.1 seconds which will be suitable for most applications and is the minimum recommended for a 30Hz source (or a 60Hz interlace source). For a 60Hz frame rate source the minimum recommended Playback Delay is 0.05 seconds.

Valid Playback Delay settings can be determined by setting values then checking the Pipeline Status Meter.

Bandwidth Monitoring Page

Playback Delay is adjusted via the Bandwidth page for the VN-MATRIX decoder. This is accessed via the video or audio hyperlink on the Display page:

The navigation path is as follows:

- Device List:** Shows a list of devices including `device620097`.
- Device [device620097]:** Shows configuration details for the selected device, including Name, Serial Number, Status, Device Type, and Mode.
- Device [device620097] > Display [display0]:** Shows configuration for the selected display, including Name, Output Format, Active Format, and Bandwidth source.
- Device [device620097] > Display [display0] > Window [videowindow]:** Shows the **BANDWIDTH MONITORING & DIAGNOSTICS** page.

BANDWIDTH MONITORING & DIAGNOSTICS

Window Name: `videowindow` Playback Delay: `0.1` sec Pipeline Status:


Source: `device620095.videoPort0_rtp`
 rtp destination: `192.168.0.2:8000`
 rtp source: `192.168.0.1:8000`

	Total	Window1	Window2
Megabits/sec	5.396	5.396	5.415
Packets/sec	121	121	122
Dropped Packets	0	0	0
Interval Time	30	<code>30</code>	<code>5</code>

`update`

Adjusting the Playback Delay

- 1 Open the Bandwidth page for the video object.



- 2 Enter a value into the **Playback Delay** field and click the **update** button.


- 3 Check the **Pipeline Status** indicator to ensure that the **Playback Delay** is at a valid level:
 -  Setting is valid and should give a stable image.
 -  Playback Delay is too small. This will result in the playback image jumping as network loading changes.
 -  Playback Delay is too large. This will increase the image latency and may result in internal buffer overflow on high bandwidth datastreams. This will cause a jumpy screen update and screen flashing.

- 4 If the source also has an audio stream, open the Bandwidth page for the audio object and adjust the Playback Delay in the same way.

HINT: To achieve lip sync between video and audio streams, adjust the video playback delay first to obtain a 'normal' meter reading, and then adjust playback delay as required.

Creating a Custom Output Mode

The **Output Format Management** screen allows the user to create bespoke video formats for displaying decoded video data streams.



There are two ways of creating bespoke video display formats:

- Clone an existing mode and modify some parameters
- Type in resolution and refresh rate values and create a CVT or GTF mode

vnmatrix

Device List Device Display **Format** Save Help Logout

Device [device620165] > Display [display0]

User Output Format Update New Format Save Formats CVT GTF Delete


Name margins ☐ reduced blanking ☐

Active Pixels	Active Lines
Total Pixels	Total Lines
Horizontal Left Border	Vertical Top Border
Horizontal Right Border	Vertical Bottom Border
Horizontal Front Porch	Vertical Front Porch
Horizontal Sync Width	Vertical Sync Width
Horizontal Back Porch	Vertical Back Porch
Horizontal Sync Polarity	Vertical Sync Polarity
Frame Rate	Pixel Clock Frequency

The Cloning Method

An existing video format is cloned by selecting an existing format from the **Name** list box then clicking on **New Format**. A popup dialog will then prompt for a new name. This should be descriptive and ideally include the resolution and frame rate. Once a user video format has been created the various timing fields can be edited. New values are typed into the appropriate fields and pressed to commit the change.

The following graphic indicates the meaning of each term. Only the active video area contains visible content. The borders are normally on screen but do not show content. The two porches and the sync together define the 'screen blanking'. This is a non-visible portion of the signal inserted to give a CRT sufficient time to reset to the start of the next line/frame.



The following relationships must hold:

- **TotalPixels** = ActivePixels + LeftBorder + RightBorder + HorFrontPorch + HorSync + HorBackPorch
- **TotalLines** = ActiveLines + TopBorder + BottomBorder + VertFrontPorch + VertSync + VertBackPorch
- **PixelClock** = TotalPixels * TotalLines * FrameRate
- **Borders** (margins) are typically only used for VGA sized modes

NOTE: It is difficult to create a video format that will be correctly interpreted by monitors without adhering quite closely to standards. If definitive timing information is not available it is suggested the following CVT/GTF approach is used.

NOTE: Interlace modes cannot be created by this or the CVT/GTF method at this time.

After a suitable video format has been created and tested it can be saved to non-volatile storage by clicking on **Save Formats**. This video format will then be available after a device reset or power cycle.

Unwanted user video formats can be deleted by selecting the video format to delete and clicking on **Delete**. A **Save Formats** operation is then required to delete this format from non-volatile storage.

The CVT/GTF Method

GTF and the newer CVT are a standardized approach to creating video formats.

To select a GTF format the user must input Active Pixels, Active Lines, Frame Rate and the margins flag, then click the **GTF** button . All other fields will then be filled in with the nearest suitable GTF video format.

A CVT video format is similarly selected. However CVT also supports the reduced blanking flag. Reduced blanking allows LCD panels, which do not require as long a blanking period as CRTs, to support a higher resolution for any fixed maximum pixel clock rate.

After a suitable video format has been created and tested it can be saved to non-volatile storage by clicking on **Save Formats**. This video format will then be available after a device reset or power cycle.

Unwanted user video formats can be deleted by selecting the video format to delete and clicking on **Delete**. A **Save Formats** operation is then required to delete this format from non-volatile storage.

System Set Up

Changing User Login Passwords

- Login to the Web Interface (see page 41).
- From the **Device List** page click the **Accounts** tab.

The following page will appear:

The screenshot shows the VN-Matrix Controller - Account Management web interface. The header features the 'vnmatrix' logo. The navigation bar includes 'Device List', 'Accounts', 'SaveAll', 'Help', and 'Logout'. The main content area is titled 'VN-Matrix Controller - Account Management'. It contains two sections: 'Administrator' and 'Public Account'. The 'Administrator' section shows 'User Name' as 'admin', 'Current Password', 'New Password', and 'Confirm' fields, and a 'Clock Management' section with 'Current Time' as '2008-04-16 09:00:38' and a 'New Time' field with a 'Change Time' button. The 'Public Account' section shows 'User Name' as 'public', 'Current Password', 'New Password', and 'Confirm' fields. At the bottom is an 'Update Passwords' button.

VN-MATRIX has two user accounts:

- **admin** – which allows full *read/write* access to all setup parameters,
- **public** – which allows *read only* access to setup parameters.

- Enter the **Current Password** for the user account you want to change.
- Then enter the new password in both the **New Password** and **Confirm** fields.

NOTE: The password can include letters, numbers and the underscore character, and is case-sensitive.

- Click the **Update** button to save the change. The new password will be required the next time you login.

Upgrading Device Firmware

From time to time Electrosonic may issue firmware upgrades for VN-MATRIX, in order to make new functionality available. Details of the latest firmware release will be published on our website.

Upgrades are supplied in a single file, named in the format '**upgrade_ver3.3c.tar**' where 'ver3.3c' is the version number. Before you start you will need to copy the upgrade file on to the computer that you use to access the VN-MATRIX controller.

The update process is split into the following stages:

Stage	Function Summary	Performed On
UPLOAD	Copy the upgrade file from the control PC to a temporary storage area on the VN-MATRIX Controller	The VN-MATRIX Controller only
PREPARE	Unpack and copy the new firmware (from the controller) into the VN-MATRIX alternate flash memory.	Each VN-MATRIX device including the controller
ACTIVATE	Reboot the VN-MATRIX to start using the new firmware. This is a temporary mode that allows you to test the new firmware. If you encounter any problems you can 'back out' of this mode and return to the previous firmware version.	Each VN-MATRIX device including the controller
COMMIT	Reboot the VN-MATRIX to start using the new firmware permanently.	Each VN-MATRIX device including the controller

All stages of the upgrade process are carried out using the Web Interface. It is recommended that all VN-MATRIX units in the same system are upgraded to the same firmware version to ensure full compatibility.

IMPORTANT NOTES:

- *Performing the ACTIVATE function on the controller will cause the device to reboot and as a result the upgrade file (in the temporary storage area) will be erased. It is recommended, therefore, that you PREPARE **all** devices first, after which the upgrade file will no longer be needed. Then perform the ACTIVATE function on each device, commencing with the controller.*
- *The ACTIVATE function must be performed on the controller device **first**, such that the new firmware is in control of upgrading the remaining devices.*
- *When performing ACTIVATE or COMMIT on the controller, the device will reboot. This will cause temporary loss of the Web Interface, since this is provided by the controller. Wait for 30 seconds to allow the device time to reboot, then 'refresh' the browser.*

To upload the firmware file to the VN-MATRIX controller...

- Login to the Web Interface (see page 41).
- From the **Device List** page click on the VN-MATRIX controller device.
- From the **Device** page click the **Upgrade** tab. The **Upgrade** page will appear:

Select Firmware Version	Committed Version	Upgrade Version	Device Upgrade Status
	ver3.0f	ver3.1c	WAIT

- Click the **Browse** button to navigate to the required upgrade file, or type the path and filename directly into the field provided.
- Click the **Upload** button to begin uploading the file to the VN-MATRIX controller. This may take a few minutes.
- Once the file is uploaded, you can begin installing it into each unit (as described on page 84) starting with the controller unit.

To install the new firmware into each VN-MATRIX unit...


IMPORTANT NOTE: You must upgrade the VN-MATRIX controller first. Please note, however, that once you go past the **READY TO ACTIVATE** stage the unit will reboot and the upgrade file will be erased from the controller. It is recommended, therefore, that you get ALL devices to the **READY TO ACTIVATE** stage before completing the controller upgrade, otherwise you will need to upload the file again (as described on page 83).

- ☞ From the **Device List** page click on the VN-MATRIX unit that you want to upgrade.
- ☞ From the **Device** page click the **Upgrade** tab. The **Upgrade** page will appear.
- ☞ Click the **Select Firmware Version** listbox and choose the new firmware file you want to install. Usually there will only be one file listed (i.e. the file that you uploaded using the procedure on page 83).

The remainder of the installation procedure is achieved using the **forward** and (if necessary) **reverse** buttons, to move the installation between the various stages. The current stage/status is indicated by the **Device Upgrade Status** field.

The process allows you to temporarily install and test the new firmware and, if everything is OK, you can then permanently install (commit) the new firmware. Up until the last stage it is possible to return to the existing firmware version.

The process is summarized in the following diagram:



- ☞ Click the **forward** button. The Device Upgrade Status field will show **PREPARE** and percentage progress. This stage may last a few minutes.

HINT: The chosen firmware version is confirmed in the *Upgrade Version* field.

- ☞ When **READY TO ACTIVATE** appears, click the **forward** button again.
- ☞ The unit will then reboot. Once rebooted the Device Upgrade Status field will show **READY TO COMMIT** and the VN-MATRIX will be using the new firmware. Test for correct operation.
- ☞ If everything is working correctly, click **forward** again to permanently install the new firmware. The Device Upgrade Status field will show **COMMITTING** and percentage progress. This stage may last a few minutes.

*If you experience any problems, click **reverse** to return to the previous stage.*

- ☞ When the Device Upgrade Status field returns to **WAIT** the unit is ready for use.

Changing a Device Licence

Each VN-Matrix unit is supplied with a default level of functionality which can be upgraded by obtaining a special license key from Electrosonic.

A license key comprises two elements – a 'structure' and a 'checksum'. These are entered using the **License** page which is accessed via the **license management** button on the **Device** page:



Enter the **New Structure** and **New Checksum** information exactly as supplied.

Click the **Update Licence** button.

SECTION 5:

Serial Transport & Control Methods

Overview

Routing of external serial (RS-232) communications can be achieved between any VN-MATRIX units on the same network.

Serial traffic can be unidirectional as part of a source stream (encoder to decoder) – Data Stream Mode - or bi-directional and independent of any source stream – Passthrough Mode.

In addition, serial commands can be sent via any VN-MATRIX device to the VN-MATRIX controller, allowing dynamic control of system parameters – Remote Control Mode.

Data Stream Mode

In this mode, data received by an encoder is transported to the decoder, along with video and audio, as part of the source stream. Data transport in this mode is unidirectional and is capable of being recorded (and played back) by VN-RECORDER.



Data input to the encoder is sent to the decoder as part of the source stream along with video and audio

Both units are set to serial Server mode

Serial ports on each VN-MATRIX need not share a common baud rate. However, where a large amount of data is sent from a high speed to a low speed data link, some form of handshaking/flow control may be required to prevent buffer overflow on the output device. Standard flow control methods are fully supported.


IMPORTANT: *No data will be transported until the decoder 'connects' to the encoder stream.*

To set up a serial data stream, see page 90.

Passthrough Mode

In this mode, data received by a device 'input' is transmitted using TCP/IP over the network and then converted back to serial data by a device 'output'. Data flow is fully bi-directional and totally independent of whether a VN-MATRIX is configured as an encoder or decoder.

One device within a passthrough group is designated as a server. One or more devices are then 'connected' as clients (in passthrough mode):



Serial ports on each VN-MATRIX need not share a common baud rate. However, where a large amount of data is sent from a high speed to a low speed data link, some form of handshaking/flow control may be required to prevent buffer overflow on the output device. Standard flow control methods are fully supported.


Any number of serial passthrough groups may exist on the same network.

To set up a serial passthrough group, see page 91.

Remote Control Mode

In addition to 'passthrough' operation outlined above, a VN-MATRIX serial input can be configured to communicate directly with the VN-MATRIX controller. This provides basic serial 'remote control' functionality of a VN-MATRIX system, such as display source switching. A full list of serial commands can be found on page 93.

One or more devices are designated as clients (in remote control mode). Data received by a device 'input' is then automatically transmitted using TCP/IP over the network to the VN-MATRIX controller:



Serial remote control functionality is totally independent of whether a VN-MATRIX is configured as an encoder or decoder.

To set up a remote control group, see page 92.

Setting-up a Serial Data Stream

- Login to the Web Interface (see page 41).
- From the **Device List** page click on the required encoder device.
- From the **Device** page click the **Serial** tab to display the following:



The screenshot shows the VN-MATRIX web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Device', 'Serial' (which is highlighted), 'Save', 'Help', and 'Logout'. Below the navigation bar is a breadcrumb trail: 'Device [device24] > Serial Port Configuration'. The main content area is orange and contains a form for serial port configuration. The form has the following fields: 'mode' (dropdown menu with 'server' selected), 'baud rate' (dropdown menu with '115200' selected), 'data bits' (dropdown menu with '8' selected), 'stop bits' (dropdown menu with '1' selected), 'parity' (dropdown menu with 'none' selected), and 'handshake' (dropdown menu with 'none' selected). Below these fields is an 'update' button. To the right of the 'update' button, the IP address '0.0.0.0' is displayed.

- Using the **mode** listbox select the **server** option.
- Change the other settings (e.g. baud rate) as required, then click the **Save** tab.
- Return to the **Device List** and do the same for the decoder device.

IMPORTANT: *No data will be transported until the decoder 'connects' to the encoder stream.*

Setting-up a Serial Passthrough Group

- ☞ Decide which VN-MATRIX unit is to be the server in the passthrough group and which will be the client(s), and connect your serial devices to the VN-MATRIX COM2 ports accordingly.

Remember, communication can only take place between server and client(s), not between clients.

- ☞ Login to the Web Interface (see page 41).
- ☞ From the **Device List** page click on the device you want to configure as the server.
- ☞ From the **Device** page click the **Serial** tab to display the following:

- ☞ Using the **mode** listbox select the **server** option.
- ☞ Change the other settings (e.g. baud rate) as required, then click the **Save** tab.


Then, for each client in the group...

- ☞ Return to the **Device List** page (by clicking on the Device List tab).
- ☞ Click on the device you want to configure as a client, then click the **Serial** tab.

- ☞ Using the **mode** listbox select the **client** option (note that this will reveal the **destination** box).
- ☞ Using the **destination** listbox select **passthrough** for the appropriate server.
- ☞ Change the other settings (e.g. baud rate) as required, then click the **Save** tab.

Setting-up a Remote Control Group

- Decide which VN-MATRIX unit(s) will act as the remote control client(s) and connect your serial control device(s) to the VN-MATRIX COM2 port(s) accordingly.
- Login to the Web Interface (see page 41).
- From the **Device List** page click on the device you want to configure as a remote control client.
- From the **Device** page click the **Serial** tab to display the following:



The screenshot shows the VN-MATRIX web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Device', 'Serial' (which is highlighted), 'Save', 'Help', and 'Logout'. Below the navigation bar is a breadcrumb trail: 'Device [device24] > Serial Port Configuration'. The main content area is orange and contains the following configuration fields:

- mode: client (dropdown menu)
- baud rate: 115200 (dropdown menu)
- data bits: 8 (dropdown menu)
- stop bits: 1 (dropdown menu)
- parity: none (dropdown menu)
- handshake: none (dropdown menu)
- destination: remote-control (dropdown menu) 0.0.0.0

At the bottom of the configuration fields is an 'update' button.

- Using the **mode** listbox select the **client** option.
- Using the **destination** listbox select the **remote-control** option.
- Change the other settings (e.g. baud rate) as required, then click the **Save** tab.

Serial / Telnet Commands

The following commands can be used to provide basic remote control of a VN-MATRIX system.

Commands can be issued either as part of a serial remote control configuration (see page 89) or by using a Telnet application via the network (see page 106).

In either case, a control session must first be initiated by sending a valid username and password.

All commands must be terminated (actioned) with a 'new line' character (carriage return not required). In programs such as Telnet, this is accomplished by pressing the Enter key.

Control Session Commands

user <username>

Initiates a user login. To be able to change system settings you must login using the 'admin' user account.

EXAMPLE: **user admin**

pass <password>

Specifies the password for the user account. By default this will be 'admin' but may have been changed using the Web Interface (see page 81).

EXAMPLE: **pass admin**

exit

Terminates the current remote control session.

Device Commands

mode <deviceid> <state>

Changes the operating mode of the specified device.

<deviceid> is the device serial number of the device or the user-defined device name.

<state> is the required mode and can be set to:

enable – for normal operation

disable – to stop encoder source streaming or stop display output on a decoder

standby – to stop encoder source streaming or display splash screen on a decoder

EXAMPLE: **mode 16 enable**

channel <deviceid> <window> <sourceid.videoport.protocol>

Changes the source being displayed in a window of the specified decoder device.

<deviceid> is the device serial number of the device or the user-defined device name.

<window> is the window object number. Currently this can only be **0**.

<sourceid.videoport.protocol> is the source to be displayed, where:

source id is the serial number of the source device,

videoport is the video input number, usually set to **0**,

protocol specifies either RTP or TCP, set to **0** for RTP or **1** for TCP.

NOTE: Full stops (.) are required between the *sourceid*, *videoport* and *protocol* values.

EXAMPLE: **channel 17 0 16.0.1**

optimization <deviceid> <videoport> <mode>

Changes the compression transform for the specified encoder device.

<deviceid> is the device serial number of the device or the user-defined device name.

<videoport> is the video input number, usually set to **0**.

<mode> is the source transform to be used and can be set to:

video – for video sources

graphics – for graphics sources

EXAMPLE: **optimization 16 0 video**

bandwidth <deviceid> <videoport> <bandwidth>

Changes the target bandwidth value for the specified encoder device.

<deviceid> is the device serial number of the device or the user-defined device name.

<videoport> is the video input number, usually set to **0**.

<bandwidth> is the bandwidth value in Megabits per second.

EXAMPLE: **bandwidth 16 0 5**

Response Messages

All commands (except for **user** and **exit**) will generate an **ok** response message if the command is successfully executed.

Unrecognized commands or invalid command parameters will generate an error message in the format **fail:** followed by a brief description of the error, for example **fail: unknown command**.

SECTION 6:

Remote Keyboard & Mouse Operation

Overview

When a PC source is being viewed by a VN-MATRIX decoder, remote keyboard and mouse control of the source PC can be achieved via the decoder unit.


For remote keyboard and mouse functionality to be possible:

- The keyboard and mouse ports of the source PC must be fully connected to the VN-MATRIX encoder (as shown on page 37 or 38),
- A keyboard and mouse must be connected to the VN-MATRIX decoder (as shown on page 39 or 40), and
- The decoder must currently be viewing the PC source.

To initiate a remote control session...

- ☞ Using the keyboard attached to the VN-MATRIX decoder, press the **Scroll Lock** key twice, followed by the **F1** key.

The **source** monitor will briefly show **MK:Remote** in the top left-hand corner...



The **display** monitor will briefly show **MK:Forward** in the top left-hand corner...





NOTE: Local keyboard and mouse control of the source will be disabled. See below for instructions on regaining local control.

To terminate a remote control session...

- ☞ Using the keyboard attached to the VN-MATRIX decoder or encoder, press the **Scroll Lock** key twice, followed by the **F2** key.

Both the **source** monitor and **display** monitor will briefly show **MK:Local** in the top left-hand corner...



SECTION 7:

Technical Data

VN-MATRIX Hardware

Mechanical Data

Overall Dimensions:	<i>Width:</i>	215mm (8.47 inches)	
	<i>Depth:</i>	308mm (12.17 inches)	<i>[including rear sockets]</i>
	<i>Height:</i>	44mm (1.74 inches)	<i>[excluding feet]</i>
		53mm (2.09 inches)	<i>[including feet]</i>
Average Weight:	1.4 kg (3.1 lbs)		

Operating Conditions

Ambient Temperature:	5°C to 35°C (41°F to 95°F).
Ambient Humidity:	85% maximum (non-condensing).
Location:	Free-standing or 19" Rack-mounting (using approved kit).
Cooling Method:	Internal fan (temperature controlled speed).

Power Supply

VN-MATRIX

Supply Voltage:	12V DC Regulated (via Mains Adapter)
Supply Current:	6A max.

MAINS ADAPTER


Supply Voltage:	100 – 240V AC nominal.
Supply Frequency:	50 – 60 Hz nominal.
Supply Current:	0.45A maximum.
Supply Inlet Connector:	IEC320 (C14).
Supply Mating Connector:	IEC320 (C13); suitable 2m (6ft) mains cord supplied.

Connectors

Keyboard/Mouse (PS/2)

Function: Keyboard and mouse pass-through connections for source computer.
 Connector Type: 6-pin mini-DIN (female)
 Pin-out Details:

(View into socket)



Pin	Function
1	Data
2	No connection
3	Ground
4	+5V supply*
5	Clock
6	No connection

** 5V on pin 4 limited to 200mA by thermal fuse.*

Mating Connector: 6-pin mini-DIN (male).
 Recommended Cable: Supplied screened PS/2 cable.
 Max. Cable Length: 2.95 metres (9.5 feet).


Digital Audio I/O (SPDIF IN and OUT)

Function: Input and Output/Loop-Through for digital audio.
 Connector Type: RCA Phono Socket

Mating Connector: RCA Screened Phono Plug
 Recommended Cable: 75Ω co-axial.
 Max. Cable Length: 10 metres (32 feet)

DVI Input (IN)

Function: Digital or analog video input for encoding.
 Connector Type: DVI-I (female).
 Pin-out Details:



Digital Connections

Pin	Function	Pin	Function	Pin	Function
1	TMDS 2-	9	TMDS 1-	17	TMDS 0-
2	TMDS 2+	10	TMDS 1+	18	TMDS 0+
3	Ground (2/4)	11	Ground (1/3)	19	Ground (0/5)
4	nc	12	nc	20	nc
5	nc	13	nc	21	nc
6	DDC Clock	14	+5V supply*	22	Ground (Clk)
7	DDC Data	15	Ground (for 5v)	23	TMDS Clock+
8	Analog V-Sync	16	Hot Plug Detect	24	TMDS Clock-

* 5V supply is provided by VN-MATRIX and limited by 200mA polyswitch.
 All ground pins are linked internally.

Analog Connections

Pin	Function
C1	Red Signal
C2	Green Signal
C3	Blue Signal
C4	Horizontal Sync
C5	Ground

NOTE:
 Analog Vertical Sync
 is on pin 8.

Mating Connector: DVI-D or DVI-I (male).
 Recommended Cable: Supplied DVI cables.
 Maximum Cable Length: 2.95 metres (9.5 feet).
 Signal Type: DVI (PanelLink® TMDS).
 Pixel Clock (DVI sources): Up to 162MHz.
 Analog Sources: VGA 640x480 @ 60,72,75,85Hz
 SVGA 800x600 @ 56,60,72,75,85Hz
 XGA 1024x768 @ 60,72,75,85Hz
 1152x864 @ 75Hz
 SXGA 1280x1024 @ 60,75,85Hz
 UXGA 1600x1200 @ 60Hz


Color Depth: 24-bit maximum.
 Scan Mode: Progressive.
 DVI Standard: DVI 1.0
 Display Data Channel
 Standard: DDC2B.
 DDC Levels: $V_{IH} = 2.4V$
 $V_{OH} = 0.9V$
 $I_{LOADMAX} = 2mA$

DVI Output (OUT)

Function: Loop-through video connection providing buffered output of the DVI IN connector.

Connector Type: DVI-I (female).

Pin-out Details:



Digital Connections

Pin	Function	Pin	Function	Pin	Function
1	TMDS 2-	9	TMDS 1-	17	TMDS 0-
2	TMDS 2+	10	TMDS 1+	18	TMDS 0+
3	Ground (2/4)	11	Ground (1/3)	19	Ground (0/5)
4	nc	12	nc	20	nc
5	nc	13	nc	21	nc
6	DDC Clock	14	+5V supply*	22	Ground (Clk)
7	DDC Data	15	Ground (for 5v)	23	TMDS Clock+
8	Analog V-Sync	16	Hot Plug Detect	24	TMDS Clock-

* 5V supply is provided by VN-MATRIX and limited by 200mA polyswitch.
All ground pins are linked internally.

Analog Connections

Pin	Function
C1	Red Signal
C2	Green Signal
C3	Blue Signal
C4	Horizontal Sync
C5	Ground

NOTE:
Analog Vertical Sync
is on pin 8.


Mating Connector: DVI-D or DVI-I (male).
 Recommended Cable: Supplied DVI cables.
 Maximum Cable Length: 2.95 metres (9.5 feet).
 Signal Type: DVI (PanelLink® TMDS).
 Pixel Clock (DVI sources): Up to 162MHz.
 Analog Sources: VGA 640x480 @ 60,72,75,85Hz
 SVGA 800x600 @ 56,60,72,75,85Hz
 XGA 1024x768 @ 60,72,75,85Hz
 1152x864 @ 75Hz
 SXGA 1280x1024 @ 60,75,85Hz
 UXGA 1600x1200 @ 60Hz
 Color Depth: 24-bit maximum.
 Scan Mode: Progressive.
 DVI Standard: DVI 1.0
 Display Data Channel Standard: DDC2B.
 DDC Levels: $V_{IH} = 2.4V$
 $V_{OH} = 0.9V$
 $I_{LOADMAX} = 2mA$

Network (I and II)

Function: Two separate network ports (labeled as I and II). Port I is used for primary network connectivity (for data transport and configuration). Port II is reserved for future expansion.

Connector Type: Shielded RJ-45 Socket.

Pin-out Details:



Pin	Function	Pin	Function
1	TX_D1+ (TX+)	5	BI_D3–
2	TX_D1– (TX–)	6	RX_D2– (RX–)
3	RX_D2+ (RX+)	7	BI_D4+
4	BI_D3+	8	BI_D4–

Mating Connector: Shielded RJ-45 Plug.

Recommended Cable: CAT 5E or CAT 6 Shielded twisted pair (STP).

Max. Cable Length: 100 metres (330 feet).

Comms Standard: 10/100/1000BASE-T (Gigabit Ethernet)

Ethernet (MAC) Address: Each address is unique and in the format 00:E0:AA:10:xx:yy

where yy is in the range 00 – FF and the same on both ports and xx is a hex value in the range 00 – 0A for port I and 10 – 1B for port II.

For example: Port I: 00:E0:AA:10:00:18

Port II: 00:E0:AA:10:10:18

IP Address: Factory-set default is:

Port I: 192.168.0.1.

Port II: 192.168.1.12 (reserved for future use).

Both are user-definable via the serial interface.


Optional DHCP mode.

RS-232 Serial I/O (COM1 and COM2)

Function: COM1 – used for low level setup or system recovery.
COM2 – used for cross-network serial communications or serial remote control of the VN-MATRIX controller.

Connector Type: 9-pin D-type (male)

Pin-out Details:



Pin	Function	Pin	Function
1	DCD	6	DSR
2	RX (data in)	7	RTS
3	TX (data out)	8	CTS
4	DTR	9	RING
5	Ground		

Mating Connector: 9-pin D-type (female) with metal cover
 Recommended Cable: 6-core plus overall screen (low capacitance),
 0.22mm² min. per core.
 Max. Cable Length: 2.95 metres (9.5 feet).
 Comms Standard: RS-232.
 COM1 Default Setting: *Baud:* 115200
Bits: 8
Parity: None
Stop Bits: 1
Flow Control: None

Serial Interface – Quick Reference

COM2 Port Settings

Baud rate: 115200
 Data bits: 8
 Parity: None
 Stop bits: 1
 Flow control: None

Login Procedure

➤ From the Login: prompt, type **config** followed by the <enter> key.

➤ When prompted for a password type **config** followed by the <enter> key.

The following menu will then appear.

Network Port 1 =====	Network Port 2 =====
1. Boot method: static [dhcp]	11. Boot method: static [dhcp]
2. address: 192.168.0.18	12. address: 192.168.1.18
3. netmask: 255.255.255.0	13. netmask: 255.255.255.0
4. gateway: 192.168.0.1	
5. broadcast: 192.168.0.255	15. broadcast: 192.168.1.255
6. mtu: 1500	16. mtu: 1500
7. controller ip: 192.168.0.18	
8. controller port: 5432	18. webserver port: 80
9. Exit	

➤ Type the menu option number required followed by the <enter> key.

➤ Where required, type the new value followed by the <enter> key.

➤ To exit the menu and return to the main command prompt type **9** <enter>

Command Options

The following commands are also supported from the main command prompt:


Exit	to logout from the session
Reboot	to force the VN-MATRIX device to restart
Ping	to test network communications with another device (see page 127).

Telnet Interface – Quick Reference

Starting Telnet

- Click the Windows **Start** button and click on **Run**.
- In the **Open** box type **telnet** then press the <enter> key.

The telnet application will start in a separate window:




Login Procedure

- At the prompt type **open** followed by the ip address of the VN-MATRIX controller and the telnet port number (9999), then press <enter>. For example:

open 192.168.0.18 9999 <enter>

- At the **command:** prompt type **user admin**, then press <enter>.
- Then type **pass** followed by a space and the appropriate password, then press <enter>.


*By default the password is **admin**, but this can be changed via the web interface, see page 81).*




- Type further commands as required (see pages 93 to 95 for command options).
- To logout type **exit** followed by <enter>.

Web Interface – Quick Reference

Menu Structure



Login Page



vnmatrix

VN-Matrix Integrated Web Management System

Login Page

User name:


Password:

Login

Use this page to:

- Login to the Web Interface (see page 41)

Device List Page



Use this page to:

- Select a device to configure (click on the appropriate device link)
- Save all current device settings (click the **Save All** tab)
- Switch to the Accounts page (click the **Accounts** tab)
- Refresh the device listing (click the **Device List** tab)

The current configuration status of each device is also identified by an icon:

 unconfigured

 a VN-MATRIX configured as a decoder (display)

 a VN-MATRIX configured as an encoder (source)


 a computer configured as a VN-MATRIX Recorder

NOTE: *Once a VN-MATRIX device has been detected and been listed on the Device List, an entry will be displayed even if the device is subsequently disconnected. All valid devices are listed by device name and followed by their current IP address. 'Offline' devices (that couldn't be contacted by the controller) are easily identified by the lack of an IP Address. In the above example, 'device620098' is currently offline.*

For further information:

- Refer to the online help (click the **Help** tab)

Accounts Page



The screenshot shows the VN-Matrix web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Accounts' (highlighted), 'SaveAll', 'Help', and 'Logout'. Below the navigation bar is a section titled 'VN-Matrix Controller - Account Management'. This section contains two main panels. The left panel is titled 'Administrator' and has fields for 'User Name' (set to 'admin'), 'Current Password', 'New Password', and 'Confirm'. The right panel is titled 'Clock Management' and has fields for 'Current Time' (set to '2008-04-16 09:00:38') and 'New Time', along with a 'Change Time' button. Below these panels is a 'Public Account' section with fields for 'User Name' (set to 'public'), 'Current Password', 'New Password', and 'Confirm'. At the bottom of the 'Administrator' section is an 'Update Passwords' button.

Use this page to:

- Change user account passwords (see page 81)
- Change the date and/or time on the VN-MATRIX controller (not required for normal encoder/decoder applications of VN-MATRIX)

For further information:

- Refer to the online help (click the **Help** tab)

Device Page

Undefined Device Type:



[Device List](#) [Device](#) [Upgrade](#) [Serial](#) [Save](#) [Help](#) [Logout](#)

Device [device620039]

Name	device620095	update
Serial Number	620039	
Status	Active	LinkStatus: Good
IP address:port(cport)	172.28.230.140:9001(5432)	

Type

Device Type	none	create source	create display
Mode	enable		

License

Structure	V1,A1,D1,mA,mH,oS,oD,Z	licence management
-----------	------------------------	------------------------------------

Source/Encoder Device Type:



[Device List](#) [Device](#) [Upgrade](#) [Serial](#) [Save](#) [Help](#) [Logout](#)

Device [device620095]

Name	device620095	update
Serial Number	620039	
Status	Active	LinkStatus: Good
IP address:port(cport)	172.28.230.140:9001(5432)	

Type

Device Type	source	change device type
Mode	enable	Identify: ☐

License

Structure	V1,A1,D1,mA,mH,oS,oD,Z	licence management
-----------	------------------------	------------------------------------

 videoPort0

 audioPort0

Display/Decoder Device Type:

The screenshot shows the VN-MATRIX web interface. At the top, there is a navigation bar with tabs: Device List, Device (selected), Upgrade, Serial, Save, Help, and Logout. Below the navigation bar, the page title is 'Device [device620097]'. The main content area is divided into several sections:

- Name:** device620097 (with an 'update' button)
- Serial Number:** 620039
- Status:** Active
- LinkStatus:** Good
- IP address:port(cport):** 172.28.230.140:9001(5432)
- Type:**
 - Device Type:** display (with a 'change device type' button)
 - Mode:** enable (dropdown menu)
 - Identify:** ☐ **Source Identify:** ☐
- License:**
 - Structure:** V1,A1,D1,mA,mH,oS,oD,Z (with a 'licence management' button)
- display0:** A section with a monitor icon and the label 'display0'.

Use this page to:

- Configure VN-MATRIX as an Encoder (see page 46)
- Configure VN-MATRIX as a Decoder (see page 51)
- Change the device type (click **change device type** button)
- Change the device name (edit the **Name** field)
- Change the device mode (edit the **Mode** field)
- Switch to configuration pages (click on **videoPort0**, **audioPort0** or **display0** links)
- Switch to Upgrade page (click the **Upgrade** tab)
- Switch to Serial configuration page (click the **Serial** tab)

For further information:

- Refer to the online help (click the **Help** tab)

License Page



The screenshot shows the vnmatrix web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Device', 'License' (which is highlighted), 'Save', 'Help', and 'Logout'. Below the navigation bar is a breadcrumb trail: 'Device [device620039] > License'. The main content area has a light orange background. It contains a table with the following information:

Name	device620039
Serial Number	620039
Structure	V1,A1,D1,mA,mH,oS,oD,Z
New Structure	
New Checksum	

Below the table is a button labeled 'Update Licence'.


Use this page to:

- Enter a new licence key to add functionality (see page 85)

For further information:

- Refer to the online help (click the **Help** tab)

Serial Page



The screenshot shows the VN-MATRIX web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Device', 'Serial' (highlighted), 'Save', 'Help', and 'Logout'. Below the navigation bar is a breadcrumb trail: 'Device [device620174] > Serial Port Configuration'. The main content area has a light orange background. On the left, there are configuration fields: 'mode' (dropdown, 'none'), 'baud rate' (dropdown, '115200'), 'data bits' (dropdown, '8'), 'stop bits' (dropdown, '1'), 'parity' (dropdown, 'none'), and 'handshake' (dropdown, 'none'). To the right of these fields is the IP address '0.0.0.0'. At the bottom left is an 'update' button.

Use this page to:

- Setup cross-network serial communications (see page 91 and 92)

For further information:

- Refer to the online help (click the **Help** tab)

Upgrade Page



The screenshot shows the VN-MATRIX Upgrade Page. At the top, there is a black header with the VN-MATRIX logo in orange and white. Below the logo, there are five navigation tabs: "Device List", "Device", "Upgrade" (which is highlighted), "Help", and "Logout". Below the header, there is a breadcrumb trail: "Device [device620174] > Upgrade". The main content area has an orange background. It starts with the text "Please specify an upgrade file to upload:" followed by a text input field, a "Browse..." button, and an "upload" button. Below this, there is a "Select Firmware Version" label and a dropdown menu showing "select upgrade". To the right of the dropdown, there are three rows of information: "Committed Version" with the value "ver3.0f", "Upgrade Version" with the value "ver3.1c", and "Device Upgrade Status" with the value "WAIT". At the bottom of this section, there are two buttons: "reverse" and "forward".

Use this page to:

- Upgrade the VN-MATRIX firmware (see page 82)

For further information:

- Refer to the online help (click the **Help** tab)

Display Page



The screenshot shows the VN-MATRIX web interface. At the top is a black header with the 'vnmatrix' logo in orange and white. Below the logo is a navigation bar with buttons: 'Device List', 'Device', 'Display' (which is highlighted), 'Format', 'Save', 'Help', and 'Logout'. Below the navigation bar is a breadcrumb trail: 'Device [device620097] > Display [display0]'. The main content area has an orange background and contains the following fields and controls:

- Name:** A text input field containing 'display0'.
- Output Format:** A dropdown menu set to 'auto'.
- Nodata Splash:** A checked checkbox.
- SoG:** An unchecked checkbox.
- Scale:** An unchecked checkbox.
- Active Format:** A text label showing 'splash_screen (1024x768@60)'.
- bandwidth:** A section with two tabs, 'source' and 'audio'. The 'source' tab is active.
- video:** A dropdown menu set to 'Please select a source' with an unchecked checkbox next to it.
- audio:** A text label showing 'none'.
- Update:** A button at the bottom left of the form.

Use this page to:

- Set up the Decoder (see page 51)
- Change the Display object name (edit the **Name** field)
- Enable/disable splash screen when no source is connected (use **Nodata Splash** checkbox).
- Switch to Bandwidth Monitoring page (click on **video** or **audio** link)

For further information:

- Refer to the online help (click the **Help** tab)

Format Page

vnmatrix

Device List Device Display **Format** Save Help Logout

Device [device620165] > Display [display0]

User Output Format Update New Format Save Formats CVT GTF Delete

Name margins ☐ reduced blanking ☐

Active Pixels		Active Lines	
Total Pixels		Total Lines	
Horizontal Left Border		Vertical Top Border	
Horizontal Right Border		Vertical Bottom Border	
Horizontal Front Porch		Vertical Front Porch	
Horizontal Sync Width		Vertical Sync Width	
Horizontal Back Porch		Vertical Back Porch	
Horizontal Sync Polarity		Vertical Sync Polarity	
Frame Rate		Pixel Clock Frequency	

Use this page to:


- Create custom output modes for a VN-MATRIX decoder (see page 78)

For further information:

- Refer to the online help (click the **Help** tab)

Bandwidth Page (display)

Video Object Selected:




The screenshot shows the vnmatrix web interface. The top navigation bar includes buttons for Device List, Device, Display, Bandwidth (selected), Save, Help, and Logout. The breadcrumb trail is: Device [device620165] > Display [display0] > Window [videowindow]. The main section is titled "BANDWIDTH MONITORING & DIAGNOSTICS". It displays the following information:

- Window Name: videowindow
- Playback Delay: 0.3 sec
- Pipeline Status: 
- Source: device620174.videoPort0_rtp
- rtp destination: 192.168.0.12:8000
- rtp source: 192.168.0.11:8000

	Total	Window1	Window2
Megabits/sec	0.105	0.105	0.104
Packets/sec	61	61	61
Dropped Packets	0	0	0
Interval Time	40	30	5

An "update" button is located at the bottom left of the table area.

Audio Object Selected:



The screenshot shows the vnmatrix web interface. The top navigation bar includes buttons for Device List, Device, Display, Bandwidth (selected), Save, Help, and Logout. The breadcrumb trail is: Device [device620165] > Display [display0] > Window [audiowindow]. The main section is titled "BANDWIDTH MONITORING & DIAGNOSTICS". It displays the following information:

- Window Name: audiowindow
- Playback Delay: 0.1 sec
- Pipeline Status: 
- Source: none
- rtp destination: :0
- rtp source: :0

	Total	Window1	Window2
Megabits/sec	0.000	0.000	0.000
Packets/sec	0	0	0
Dropped Packets	0	0	0
Interval Time	0	30	5

An "update" button is located at the bottom left of the table area.

Use this page to:

- Change the Window object name (edit the **name** field)
- Optimize Playback Delay (see page 77)
- Monitor window bandwidth and diagnostic information

For further information:

- Refer to the online help (click the **Help** tab)

Configure Page

Video Port Selected:

The screenshot shows the vnmatrix web interface. At the top, there is a navigation bar with the vnmatrix logo and buttons for Device List, Device, Configure (selected), Video Setup, Save, Help, and Logout. Below the navigation bar, the breadcrumb path is "Device [device620174] > VideoPort [videoPort0]".

The main configuration area for VideoPort [videoPort0] includes:

- name:** videoPort0 (with an update button)
- Input Mode:** auto
- Current Mode:** SXGA 60Hz
- Source Status:** active
- Bandwidth Management:** A button to manage bandwidth.
- Monitor Edid:** No Device
- Reported Edid:** transparent (dropdown menu)

Below the configuration fields, there is a section for Streams:

- Streams:** A button to expand the streams section.
- Multicast Enable:** A checkbox that is currently unchecked.
- New Export Stream:** A button to add a new export stream.

A table lists the current export streams:

Connection	Destination	Transport	Scope	IP address	IP port	Delete
1	device620165.videowindow	rtp	internal	192.168.0.12	8000	

Audio Port Selected:

The screenshot shows the vnmatrix web interface. At the top, there is a navigation bar with the vnmatrix logo and buttons for Device List, Device, Configure (selected), Save, Help, and Logout. Below the navigation bar, the breadcrumb path is "Device [device620174] > AudioPort [audioPort0]".

The main configuration area for AudioPort [audioPort0] includes:

- Name:** audioPort0 (with an update button)
- Audio Status:** Unknown / Inactive / Unknown Type
- Compression:** no compression (dropdown menu)

Below the configuration fields, there is a section for Streams:

- Streams:** A button to expand the streams section.
- Multicast Enable:** A checkbox that is currently unchecked.
- New Export Stream:** A button to add a new export stream.

A table lists the current export streams:

Connection	Destination	Transport	Scope	IP address	IP port	Delete

Use this page to:

- Setup the source input for an encoder (see page 46)
- Change the videoPort object name (edit the **Name** field)
- Change the input mode (edit the **Input Mode** field)

- Switch to the Video Setup page (click the **Video Setup** tab)
- Switch to the Video Bandwidth & Compression Management page (click on the **Bandwidth Management** button)

For further information:

- Refer to the online help (click the **Help** tab)

Video Setup Page

name: videoPort0

mode: auto phase: auto macrovision defeat: ☐ colour space: RGB

Resync Update blanking: auto pixels: 0 lines: 0

Device Status

currentMode	: SXGA 60Hz
type	: analog hv progressive
source status	: active
stream status	: (1,1)
lockStatus	: 1
monLineCount	: 1066
monLinePeriod(ns)	: 15600
digHSize	: 1278
digVSize	: 1024
digFirstPixel	: 370
digFirstLine	: 41
phase	: 16

User Source Format New Source Save Source

Name	:	
LineCount	:	
LinePeriod(ns)	:	
PixelsPerLine	:	
HSize	:	
VSize	:	
FirstPixel	:	
FirstLine	:	

Interlace: ☐ Fixed Geometry: ☐ Trisync Ignore: ☐


Use this page to:

- Fine-tune an auto-detected source (see page 65)
- Create or modify a source input mode (see page 66)
- View current source setup for a 'detected' source

For further information:

- Refer to the online help (click the **Help** tab)

Bandwidth Page (source)



The screenshot shows the vnmatrix web interface. At the top is a navigation bar with the vnmatrix logo and buttons for Device List, Device, Configure, Bandwidth (selected), Save, Help, and Logout. Below the navigation bar is a breadcrumb trail: Device [device620039] > VideoPort [videoPort0]. The main content area is titled "Bandwidth Management" and contains two columns of settings. The left column includes Compression settings (Luminance: 5, Chrominance: 7, Lock: checked), Quality Control (Advanced), Temporal (checked), Threshold (0), Refresh Rate (1), Transform (graphics), and Motion (0). The right column includes Bandwidth settings (Mode: none, Target Bandwidth (Mbps): 0.000, Frame Drop Percentage: 0). Below these settings is a "Streams" section with a plus icon and a text input field. An "update" button is located at the bottom left of the settings area.

vnmatrix

Device List Device Configure **Bandwidth** Save Help Logout

Device [device620039] > VideoPort [videoPort0]

Bandwidth Management

Compression

Luminance 5 Lock: ☒

Chrominance 7

Quality Control Advanced

Temporal ☒

Threshold 0 Chroma ☐

Refresh Rate 1

Transform graphics

Motion 0

Bandwidth

Mode none

Target Bandwidth (Mbps) 0.000

Frame Drop Percentage 0

Streams

update

Use this page to:

- Change bandwidth management and compression settings for a source (see pages 71 & 72)

For further information:

- Refer to the online help (click the **Help** tab)

APPENDIX A:

Guide to IP Addressing

What is an IP Address?

A full explanation of IP addressing is beyond the scope of this user guide. However the following details will provide you with enough information to get started.

An IP Address is a 32-bit binary number that is used to identify each device on an Ethernet network. This number is usually represented by four decimal numbers (each in the range 0 to 255) separated by dots, e.g. 198.123.34.240. This is called 'dotted decimal notation'.

An IP Address is divided into two parts:

- the 'network identifier', and
- the 'host identifier'.

On a given network each address must have the same network identifier value but have a unique host identifier. There are, therefore, different 'classes' of address which define:

- the range of valid addresses, and
- which parts of the address are used for the network and host identifiers.

The most common IP Address classes are:

Class Name	Valid Address Range	Identifier Arrangement*
Class A	0.0.0.1 to 127.255.255.254	NNN.HHH.HHH.HHH
Class B	128.0.0.1 to 191.255.255.254	NNN.NNN.HHH.HHH
Class C	192.0.0.1 to 223.255.255.254	NNN.NNN.NNN.HHH

*Where: NNN = Network identifier
HHH = Host identifier

Private & Public Address Ranges

Within each of the above classes are a range of addresses designated as 'private' addresses. These are addresses which should only ever be used on private local networks and intranets and cannot be accessed directly from the internet.

10.0.0.0 – 10.255.255.255
 172.16.0.0 – 172.31.255.255
 169.254.0.0 – 169.254.255.255
 192.168.0.0 – 192.168.255.255

All other addresses outside these ranges are considered 'public' addresses.

Multicast Address Range

A further range of addresses are available for multicast usage:

224.0.0.0 – 239.255.255.255

These addresses (also known as Class D addresses) are used to allow several devices to be part of the same multicast group. Each device in the group has the same multicast address and can effectively send data to all other devices in the same group simultaneously.

Choosing IP Addresses

If your VN-MATRIX units are connected via their own independent network, then follow the guidelines below for choosing your IP Addresses.

However, if you intend connecting your VN-MATRIX units to an existing network, you will need to advise the network administrator and ask them to allocate suitable addresses to you.

On an independent network you can (in theory) use just about any addresses you wish. However, it is generally recommended that you use the Class C format (*i.e.* from 192.0.0.1 up to 223.255.255.253).

Remember that there are two rules for choosing IP Addresses:

- the network identifier must be the same for each address, and
- the host identifier must be unique for each address.

Applying these rules to Class C addresses, it can be seen that the first three decimal values of your IP Addresses must all be the same, while the last value is used to uniquely identify each device.

The following is an example of a valid Class C addressing scheme:

Device	IP Address
Device 1	208.132.180.41
Device 2	208.132.180.42
Device 3	208.132.180.43

NOTE: *The host identifiers (e.g. 41, 42, and 43 in the above example) need not be sequential or in any particular order. However, it is recommended that you group the numbers for simplicity.*

The following is an example of an **invalid** Class C addressing scheme:

Device	IP Address
Device 1	208.132.180.41
Device 2	192.157.180.42
Device 3	209.100.123.43

NOTE: *These are invalid because the network identifier for each address is not the same, even though each IP Address is unique.*

You can use the Ping command from your computer to check that a device at a particular address is responding correctly (see page 127).

Subnet Mask

The Subnet Mask is another 32-bit binary number that is used to 'mask' certain bits of the IP Address. This provides a method of extending the number of network options for a given IP Address. It works by allowing part of the host identifier to be used as a 'subnet identifier'. Any further explanation of this facility is not relevant here.

However, it is important that you set the correct value for the Subnet Mask. The basic values depend on the class of IP Address being used:

Class Name	Subnet Mask
Class A	255.0.0.0
Class B	255.255.0.0
Class C	255.255.255.0

Using the 'Ping' Utility to Test Communications

You can test for communications between a Windows computer and another device on the same network by using the Windows Ping utility.

- From the Windows Desktop of the computer, click on the **Start** button, and select **Run** from the pop-up menu.

The Run dialog box will appear.

- In the Open box, type in the following command:

```
ping xxx.xxx.xxx.xxx -t
```

where xxx.xxx.xxx.xxx is the IP Address of the device (e.g. a VN-MATRIX) that you want to test.

- Click on the **OK** button or press the **Enter** key.

A text window will appear showing a series of response messages; these are explained below.

- To stop the ping utility, press **Ctrl + C** on the keyboard.

HINT: Ping can also be run from the command line of the serial interface (see page 105).

Response Messages

When you run the Ping utility, it will display a series of response messages, which you can use to determine the state of the communications link. For example, if you have 'pinged' a device with the address 208.132.180.48, you should get a message similar to the following:

```
Reply from 208.132.180.48: bytes=32 time=2ms TTL=32
```

This is the correct response which indicates that the device at the specified address is communicating correctly. Note that the response 'time' value may vary according to network traffic.

If you get the message...

```
Request timed out.
```

...this indicates that there has been no response from the specified address. Either the processor is not receiving data from the computer or not sending data back. Check that the device is powered-up and set to the same address that you 'pinged'. Also, check that you are using the correct type of connecting cables (i.e. 'straight through' or 'crossover') and that they are not damaged or faulty.

If you get the message...

```
Reply from 208.132.180.48: Destination host unreachable.
```

...this indicates that the IP Address of the computer is not in the same 'class' (or subnet) as that of the device being 'pinged'. Check that the SubNet Mask on both the computer and the device are set to the same value (see page 126). Also check that both IP Address are within the correct range for the chosen class and are compatible (see page 126).

APPENDIX B:

Understanding Network Performance


Network Characteristics

There are a number of characteristics of networks that have to be taken into account when transmitting image data.

When a conventional analog or digital video signal is sent from a source to a display, the image is transmitted in real time with negligible delay (or “latency”). The signal itself is continuous with (even in the case of a digital signal) very little redundancy in the signal (i.e. the great majority of the signal is image data, so little bandwidth is “wasted”). In general the signal is not subject to any unpredictable degradation.

Data Packets/Frames

If a digital image stream is sent across a network, it must be “packetized”. The network itself is indifferent to the nature of data, and simply treats all digital information in a standard way. Before it can be sent over a network, the data must be re-formatted into packets called “IEEE MAC frames”.



IEEE802.3 Media Access Control frame.

Some points arise from this:

- The data carried within a frame/packet is limited to the MTU (maximum transmission unit) of the network, typically 1500 bytes.
- The data must include any additional overhead arising from the protocol being used (e.g. UDP or TCP/IP).

The MTU is the largest physical packet size (measured in bytes) that a network can transmit. Any messages larger than the MTU are divided into smaller packets before being sent.

The introduction of Gigabit (1 Gb/s) Ethernet has allowed the introduction of “Jumbo” frames with more than 1500 data bytes. Clearly the overhead involved by limiting the number of bytes to 1500 is considerable, and using jumbo frames makes more efficient use of the network. However, the following should be noted:

- Many real world networks only operate at 100Mb/s at local level and these can NOT accept jumbo frames.
- Even many gigabit networks are not configured to accept jumbo frames. Only networks so configured can use them.
- The maximum data size of a jumbo frame is 9000 bytes; and typically jumbo frames carry 8000 data bytes.
- While network efficiency goes up with larger frames, the effect of a lost frame or packet is more serious.

Nodes, Switchers & Routers

An Ethernet Local Area Network (LAN) will have a number of nodes, and in principle all nodes can communicate with each other. The principle used is “Carrier Sense, Multiple Access/Collision Detection” or CSMA/CD. This means that when not transmitting, all nodes are listening. When a node transmits no other node attempts transmission. However, signal speed limits mean that a “collision” is possible. Such collisions are detected and the competing parties “back off” for another attempt. The principle works well for small networks, but introduces inefficiency in networks with high traffic.

Networks are in practice, therefore, constrained by the use of various switching and routing devices.

- An Ethernet **hub** simply allows nodes to be connected together and CSMA/CD applies.
- An Ethernet **switch** intelligently routes internode traffic; i.e. nodes only receive traffic addressed to them. This reduces or eliminates bus contention at the local level. A switch can also allow a node to operate duplex communication i.e. simultaneous transmit and receive.
- An Ethernet **bridge** is a two port switch used for segmenting networks or joining dissimilar media.
- An Ethernet **router** connects multiple networks, and connects to networks of other types.

Routers and switches use *routing tables* to determine how traffic is directed. These can be dynamic, in the sense that they are generated as needed by examining the traffic; but they can also be static, imposing strict rules about how traffic is directed.

This factor is of great importance in respect of transmitting image data over networks. In practice unless a network is specifically programmed to carry image data, it is likely that the data will be blocked at the first router it encounters.


Protocols

For communication to work over networks there must be some formality about how communication is done in order to ensure inter-operability between different systems. The ISO proposed a model for this in its Open Systems Interconnection (OSI) model. It defines seven different “layers” for any intercommunication protocol, starting at the bottom with a “physical” layer (which might be Ethernet, wireless or some standard serial communications method) going to the top which is the “application” layer relating to the actual task in hand.

The OSI model is used as a reference, and while some systems follow the full model, others simplify it by combining the functions of certain layers. In particular the protocol stack which is the basis of standard Ethernet communication only has four layers, as indicated in the figure below.

The Internetwork layer combines the functions of the Data Link and Network layers of the OSI model and looks after addressing, carrying Internetwork Protocol (IP) within the MAC frame. The current version of Internetwork protocol is IPv4 which uses a 32 bit address. IPv6 with 128 bit addressing is being introduced to solve the possible problem of running out of available IP addresses and to provide certain other enhancements.

The Transport layer is possibly of most significance in respect of sending images over networks. It is here that data is formatted into *datagrams* suitable for transmission by IP. Here there are two significant protocols, User Datagram Protocol (UDP) and Transmission Control Protocol (TCP).



The OSI model (left) defines seven layers of interconnection. The system behaves as if, at each layer, there is direct connection between each node; but in fact communication is through the layers. With Ethernet and most data networks the preferred model is the TCP/IP four layer protocol stack (right).

Comparison between UDP and TCP

The two different transport layer protocols are compared in the following table:

UDP	TCP
Connectionless	Connection oriented
Datagrams must be formatted in application	Automatically generates datagrams from bitstream
Multiple applications using ports	Multiple applications using ports
Unreliable (best effort) communication	Reliable (guaranteed) communication
No flow control (must be in application if required)	Flow control (deals with out-of-order data and error corrections)
No error recovery	Error recovery
Multicast possible (one to many)	One to one only
Minimum latency	Significant latency

Clearly the most significant difference is that UDP is “best effort” and TCP is “guaranteed delivery”. TCP is used in most networks for such tasks as exchanging file information between nodes, because here absolute accuracy is required and because the delivery requirement is usually “point to point”.

The table implies several different methods of transmission, for example:

- **Broadcast** where a message goes to all nodes on the network. Must be UDP.
- **Unicast** where a message goes from one node to another. Must be TCP.
- **Multicast** where a message goes from one node to many nodes, each assigned to a multicast address group. Must be UDP.

The table has great significance in respect of transmitting images over networks. A few of the points that arise from it are as follows:

- Many if not most applications will involve the transmission of an image from one node to many nodes, *i.e.* multicast operation is required, mandating the use of UDP.
- Many if not most applications will require minimum latency, again indicating the use of UDP.
- But UDP does not provide “reliable” communication, so any application has to take into account the effect of lost data packets, out-of-order packets, and errors.
- Time critical data like video is often sent using an additional protocol called RTP (Real Time Protocol). This “time stamps” the packets and can be used to endow UDP with some measure of flow control.

These are not trivial issues. If a data bit goes missing in a dedicated digital video link like SDI the result is not catastrophic – its effect is at a single pixel level within a single video frame. If a data bit goes missing in an MPEG stream it can prevent the reconstruction of an entire group of images.

APPENDIX C:


Browser Configuration

Internet Explorer (v6 or above)

- ☞ Open Internet Explorer and from the **Tools** menu choose **Internet Options** to open the Internet Options dialog.


To enable cookies...

- ☞ Select the **Privacy** tab and, if required, adjust the slider control to set the required security level. VN-MATRIX will operate correctly up to and including **Medium High**.




IMPORTANT: Setting the security slider to **Block all cookies** will prevent the VN-MATRIX web interface from operating.

HINT: If you need to use a **High** security level, you can click on the **Edit** button and allow the VN-MATRIX web interface to use cookies. For example:




To enable JavaScript...

- Select the **Security** tab.



- Click the **Custom Level** button. The Security Settings dialog will appear:




- Scroll down to the **Scripting** setting and, under **Active scripting**, select **Enable**.
- Click **OK** on both dialogs to close and save the new settings.

Mozilla (v1.3 or above)

☞ Open Mozilla and from the **Edit** menu select **Preferences** to open the Preferences dialog.

To enable Cookies...


☞ Go to the **Privacy & Security** category and choose **Cookies**.



☞ Ensure that either the **Enable all cookies** or **Enable cookie for the originating web site only** option is selected.

To enable JavaScript...

☞ Go to the **Advanced** category and choose **Scripts & Plugins**.



☞ Ensure that the **Enable JavaScript for Navigator** option is selected.

☞ Click **OK** to close the dialog and save the settings.

ELECTROSONIC

UK - London

Hawley Mill, Hawley Road, Dartford, Kent. DA2 7SY
Tel: +44 1322 222 211 Fax: +44 1322 282 282
E-mail: information@electrosonic-uk.com

Sweden - Stockholm

Åsögatan 155, S-116 32 Stockholm, Sweden
Tel: +46 8 522 057 00 Fax: +46 8 223 181
E-mail: info.sweden@electrosonic.com

USA - Minneapolis

10320 Bren Road East, Minnetonka, MN 55343
Tel: +1 952 931 7500 Fax: +1 952 938 9311
E-mail: information@electrosonic.com

USA - Los Angeles

3320 North San Fernando Blvd, Burbank, CA 91504
Tel: +1 818 566 3045 Fax: +1 818 566 4923
E-mail: information@electrosonic.com

USA - New York

Suite 204, 36-36 33rd Street, Long Island City, NY 11106
Tel: +1 609 349 8600 Fax: +1 718 349 8635
E-mail: information@electrosonic.com

USA - Orlando

Suite 105, 4501 Vineland Road, Orlando, FL 32811
Tel: +1 407 839 1154 Fax: +1 407 839 2055
E-mail: information@electrosonic.com

Shanghai

Suite 1003, Block A, Shanghai Universal Mansion
172 Yu yuan Road, Shanghai 200040
Tel: +86 21 6249 2522 Fax: +86 21 6249 3358
E-mail: infoCHINA@electrosonic.com

Web Site: www.electrosonic.com

Copyright © 2008 ELECTROSONIC Ltd
All rights reserved

Part No. I458GB issue 6