

MBD 149 Rack Mounting Kit • Installation Guide

Install the Extron MBD 149 Mounting Kit brackets on an Extron 1U high, full rack width product and mount it to a standard equipment rack as follows:

1. If necessary, remove rubber feet from the bottom of the device to be installed.
2. Attach a mounting bracket on each side the device using three included flat head machine screws per bracket (see **1** in the figure at right). Some products may require only two screws.
3. Fasten the device to the rack.
 - a. Insert the device into the rack (**2**).
 - b. Insert the larger pan head machine screws (included) through the front bracket slots and into the rack (**3**).
 - c. Use a screwdriver to hand tighten the screws to secure the brackets to the rack.

