



LockIt™ Cable Adapter Tether Kit • Installation Guide

The LockIt Cable Adapter Tether provides a simple method to link cables and adapters together to prevent them from being stolen or lost. To install the tether, follow these instructions and see the figures at right.

1. Thread one end of the nylon coated wire through a heat shrink wrap (1a) and the metal loop sleeve (1b), leaving about 2 inches (51 mm) of free wire.
2. Loop the free end of the wire around the first cable to be secured and thread the end of the wire back through the metal loop sleeve (2).
3. Tighten the wire (3) until about 1/4 inch (6.4 mm) of the short end extends past the metal sleeve (3a). To avoid damaging the cable, allow about 1/8 inch (3.2 mm) of space between the wire and the cable (3b).
4. Crimp the metal loop sleeve with a pair of pliers to secure the wire in place (4).
5. Slide the wrap over the metal loop sleeve (5) and heat it to shrink it in place.
6. Repeat steps 1-5 to secure the other end of the wire to a second cable (6).

