

PROJ. ON	PROJ. OFF	PROJ. 1 ON	PROJ. 1 OFF	PROJ. 2 ON	PROJ. 2 OFF	PROJ. ON/OFF	PROJ. 1 ON/OFF	PROJ. 2 ON/OFF	TV / VCR	AUTO SYNC
MENU	ENTER	RECALL	MODE	TITLE	EXIT	PIP	CANCEL	NORMAL	RESET	AUTO
ON/OFF	STANDBY	STANDBY /ON	ON	OFF	BLANK	APA	SET	HELP	FREEZE ON	FREEZE OFF
MENU ON	MENU OFF	FOCUS IN	FOCUS OUT	BLANK ON	BLANK OFF	AUTO IMAGE	CHANNEL UP	CHANNEL DOWN	DISPLAY MUTE	DISPLAY UNMUTE
RESIZE	ZOOM IN	ZOOM OUT	MUTE	MUTE ON	MUTE OFF	AV MUTE	AV UNMUTE	AUDIO MUTE	AUDIO UNMUTE	AUTO SET UP
PRESET	PRESET 1	PRESET 2	VIDEO	VIDEO 1	VIDEO 2	VIDEO 3	ASPECT	POWER ON	POWER OFF	AUTO FOCUS
RGB	RGBHV	RGBHV 1	RGBHV 2	RGBHV 3	PC	PC 1	PC 2	PC 3	PC 4	PC 5
PC 6	LAPTOP	LAPTOP 1	LAPTOP 2	LAPTOP 3	LAPTOP 4	LAPTOP 5	LAPTOP 6	CABLE	CABLE TV	S-VIDEO
AUX VIDEO	AUX PC	LECTERN PC	CAMPUS TV	CD AUDIO	LIGHT	LIGHT ON	LIGHT OFF	LIGHTS	LIGHT ON/OFF	RADIO
MIC	WIRELESS MIC	SHADES OPEN	SHADES CLOSE	STOP	STOP	CABINET PC	CABINET VCR	RACK PC	RACK VCR	AUX AUDIO
VCR	DVD	DVD/ VCR	PLAY	PAUSE	PREV/ REW	NEXT/ FWD	SCREEN UP	SCREEN DOWN	PROJ. LIFT UP	PROJ. LIFT DOWN
VGA	NEXT	CC ON	CC OFF	CC ON/OFF	TUNER	TV TUNER	WALL PLATE	WALL PLATE 1	WALL PLATE 2	WALL PLATE 3
WALL PLATE 4	WALL PLATE 5	WALL PLATE 6	FLOOR BOX	FLOOR BOX 1	FLOOR BOX 2	FLOOR BOX 3	FLOOR BOX PC	FLOOR BOX VIDEO	DOC CAM	PIC MUTE
PLASMA ON	PLASMA OFF	PLASMA 1 ON	PLASMA 1 OFF	PLASMA 2 ON	PLASMA 2 OFF	PLASMA ON/OFF	PLASMA 1 ON/OFF	PLASMA 2 ON/OFF	DISPLAY ON	DISPLAY OFF
DISPLAY 1 ON	DISPLAY 1 OFF	DISPLAY 2 ON	DISPLAY 2 OFF	DISPLAY 3 ON	DISPLAY 3 OFF	DISPLAY ON/OFF	DISPLAY 1 ON/OFF	DISPLAY 2 ON/OFF	DISPLAY 3 ON/OFF	IPOD