

Quarter-rack Width Product Mounting Bracket Installation Instructions

Furniture mount or projector mount the quarter-rack width product using the optional mounting kit (part #70-212-01, furniture; or 70-217-01, projector) as follows:

1. Attach the mounting brackets to the product with the machine screws provided (see the figure on the other side of this card).
2. If feet were previously installed on the bottom of the product, remove them.

For furniture mounting —

3. Hold the product with the attached brackets against the underside of the table or other furniture. Mark the location of the screw holes of the bracket on the mounting surface.
4. Drill 3/32" (2 mm) diameter pilot holes, 1/4" (6.3 mm) deep in the mounting surface at the marked screw locations.
5. Insert #8 wood screws into the four pilot holes. Tighten each screw into the mounting surface until just less than 1/4" of the screw head protrudes.
6. Align the mounting screws with the slots in the brackets and place the product against the surface, with the screws through the bracket slots.
7. Slide the product slightly forward or back, then tighten all four screws to secure the product in place.



Extron Electronics, USA
1230 South Lewis Street
Anaheim, CA 92805
USA
714.491.1500
Fax 714.491.1517

Extron Electronics, Europe
Beeldschermweg 6C
3821 AH Amersfoort
The Netherlands
+31.33.453.4040
Fax +31.33.453.4050

Extron Electronics, Asia
135 Joo Seng Road, #04-01
PM Industrial Building
Singapore 368363
+65.6383.4400
Fax +65.6383.4664

Extron Electronics, Japan
Daisan DMJ Building 6F
3-9-1 Kudan Minami
Chiyoda-ku, Tokyo 102-0074 Japan
+81.3.3511.7655
Fax +81.3.3511.7656

68-705-01
Rev. A
07.02
Printed in the USA

Quarter-rack Width Product Mounting Bracket Installation Instructions, Cont'd

For projector mounting —

8. Using a locally-supplied nut and bolt, or other appropriate hardware, secure the product to a projector mount or other surface by inserting the mounting hardware through the bracket's slotted hole.

