Extron

DP to HDMI 4K PLUS Adapters • Installation Guide

The Extron DP to HDMI 4K PLUS adapter, pigtail, and cable are one-way DisplayPort adapters that allow conversion and transmission of digital signals from any DisplayPort enabled source to an HDMI sink. The adapters support resolutions up to 4096x2160 at 60 Hz 4:4:4, with EDID and HDCP information passed through between the source and the display.

NOTES:

- The cables are unidirectional and not intended to convert an HDMI source to output a DisplayPort signal.
- The cables must be used directly at the DisplayPort source. Do not use additional cables or adapters between the source output and the DP end of the cable.








(DPM-HDF 4K PLUS)

(DPM-HDF/0.5 4K PLUS)


(DPM-HDF/6 4K PLUS)

Application Diagram




Lockit Cable Adapter Tether

To prevent the adapter from being lost or stolen, attach an optional Locklt Cable Adapter Tether (available at **www.extron.com**) to link the cable and adapter together, as follows:



DP to HDMI 4K PLUS Adapters • Installation Guide (Cont.)




LockIt Lacing Bracket

Use the LockIt Lacing Bracket to securely fasten an HDMI cable to a device as follows:

- Plug the HDMI cable into the rear panel HDMI port.
- 2 Loosen the HDMI connection mounting screw from the panel, enough to allow the LockIt lacing bracket to be placed over it. The screw does not need to be removed.
- OPlace the Locklt lacing bracket on the screw and against the HDMI connector. Then, tighten the screw to secure the bracket.

ATTENTION:

- Do not overtighten the HDMI connector mounting screw. The shield it fastens to is very thin and can easily be stripped.
- Ne serrez pas trop la vis de montage du connecteur HDMI. Le blindage auquel elle est attachée est très fin et peut facilement être dénudé.
- Loosely place the included tie wrap around the HDMI connector and the LockIt lacing bracket as shown.



While holding he connector securely against the lacing bracket, use pliers or similar tool to tighten the tie wrap. Then, remove any excess length.